

Index

- 2D data, imported, layers, 809–810
- 2D sketches
 - feature-based modeling and, 15–16
 - Wrap feature, 271–272
- 3 Point Arc tool, 69
- 3D Drawing View, 749–750
- 3D Drawing View tool, 150
- 3D geometry, 113
- 3D Interconnect, 1051–1052
- 3D patterns, 291
- 3D planes, 203
- 3D Planes PropertyManager, 203
- 3D Sketch Plane tool, 71
- 3D Sketch tool, 65
- 3D sketches
 - dimensions, 204
 - extruding from, 220
 - Instant 3D, 221
 - Layout feature, 505
 - mirroring in, 291
 - navigating in space, 201–202
 - path segments, planar, 204
 - relations, 202–203
 - space handle, 201
 - weldments, 1017–1018
 - dimensions, 1021–1022
 - navigating, 1018–1019
 - path segment limits, 1021
 - plane creation, 1020–1021
 - sketch relations, 1019
- 3D solids, mirroring, 308–310
- 3D surfaces, extruding, 910

A

- absorbed sketches, 372
- ACIS, imported geometry and, 1049
- activation, Help menu options, 6–7
- Add Dimensions option, 66
- Add Relation PropertyManager, 71
- Add Relation tool, 71
- Add Relations dialog box, 71
- Add Relations tool, 89
- Advanced and Mechanical mates, 462
- Advanced interface, 12
- Alerts tab (Welcome dialog), 7
- Align Collinear/Radial alignment tool, 803
- Align Parallel/Concentric alignment tool, 803

- alignment
 - annotations, 802–803
 - breaking, 803
 - Dimension palette, 803–804
 - dimensions, automatic, 804
 - grid snapping, 803
 - inferencing, 803
 - notes, 771
 - balloons, 771–772
 - tools, 803
 - views, 750–751
- All in This Sketch category, 22
- alternate position views, 745–747, 849–850
- Alt-key combinations, 51–52
- Ambient Occlusion tool, 152
- Animated Explode/Collapse option, 852–853
- animation, 669. *See also* motion; MotionManager
 - action speed, 693–694
 - assemblies
 - closing exploded, 681–682
 - explodes, 678–681
 - timelines, rotation in, 681
- Basic Motion
 - chains, 698–700
 - contact, 696–697
 - gravity, 696–697
 - motors, 697, 698–700
 - springs, 698–700
- cameras, paths, 688–690
- compressors, 695
- configurations, 671
- contact, 672
- dampers, 672
- display, 673
- dynamic, 672
- exploded view, 677–678
- force, 672
- free motion, 672
- friction, 672
- gravity, 672
- key points and, 672, 684, 691–692
 - copying motion, 693
 - creating, 685–686
 - Disable Playback of View Keys, 684
 - interpolation, 687
 - mirroring motion, 693
 - mistake correction, 687–688
 - Orientation and Camera Views, 684
 - timebar, 685, 692–693

- view manipulation, 686
 - zooming, 686
 - kinematic, 672
 - Mate Controller, 700–702
 - mates, 672, 682–683
 - angle, 671
 - distance, 671
 - MotionManager, 670
 - motors, 672
 - outputting, 694–695
 - parts
 - appearance, 671
 - camera, 671
 - dimensions, 671
 - position, 671
 - transparency, 671
 - views, 671
 - visibility, 671
 - zoom, 671
 - PhotoView 360 and, 671
 - planning, 672
 - playing, 677
 - RealView, 673
 - rotating, 674–677
 - SolidWorks Visualize, 673
 - springs, 672
 - testing animations, 695
 - views, key points, 684–688
 - zooms, 682
- Animation Wizard, 669, 671, 674–683
- Annotation Link Variable, 767
- Annotation PropertyManager, 772–773
- annotation views, 156–157, 728–729
 - reference dimensions, 792
- annotations
 - alignment, 802–803
 - grid snapping, 803
 - inference, 803
- Design Library, 541
- notes
 - adding, 775
 - alignment, 771
 - balloons, 771–772
 - custom properties, 774–775
 - Fit Text button, 767
 - fonts, 766, 772–773
 - Format Painter, 774
 - leaders, 769–771
 - Linear Note Pattern PropertyManager, 767–769
 - patterns, 767–769
 - placing, 769–770
 - styles, 772–773
 - symbols and, 779
 - text boxes, 766–767
 - text wrapping, 766–767
 - workflow, 765–766
 - tutorials, 782–784
- Annotations toolbar
 - CommandManager, 138
 - Note button, 765
- ANSI standards, 8
- appearance overrides, 590–591
- appearances, 160
 - Display States and, 163
 - versus* materials, 159–160
 - Overrides, 160–163
 - removing, 164–165
 - views, applying, 157–158
- Appearances (DisplayManager), 157, 160
 - Appearance filter, 158
 - Appearance palette, 158
 - appearances *versus* materials, 159–160
 - applying appearances, 157–158
 - Context toolbar, 158
 - Display States, 163
 - Overrides, 160–163
 - removing appearances, 164–165
- Appearances PropertyManager, 160–163
- Application window controls, 26
- Apply Scene tool, 152
- Arc tool, 62
- arcs
 - rectangles, 187
 - tangent arcs, 69
 - three-point, 69
- Area Hatch/Fill PropertyManager, 857
- arrow keys, 144
- assemblies, 8, 415–416. *See also* large assemblies
 - animation
 - closing exploded, 681–682
 - explodes, 678–681
 - timelines, rotation in, 681
 - BOM (Bill of Materials), 436–437
 - bottom-up assembly, 422
 - chamfers, 554–555
 - color, layers, 811–812
 - Component Selection tool, 528–532
 - creating, 125–126
 - degrees of freedom, 459–460
 - design
 - base parts, 416–417
 - bottom-up with mates, 416–417
 - bottom-up with skeleton, 418
 - in-context design, 419
 - mates, 416–417
 - display states, 590–592
 - Dynamic Assembly Motion, 459
 - elements, 422–423

- equations, 423–424
 - configurations and, 425
 - external references, 424
 - global variables, 424
 - renaming, 424
 - exploded, views, 850–854
 - FeatureManager, 126
 - features, applying, 430–431
 - Fillet Beads, 1036–1038
 - fillets, 554–555
 - folders, 438–440
 - layout sketches, 426–427
 - library, 543
 - mates, 127–128
 - Mates folder, 638
 - solving, 435
 - modeling
 - base parts, 416–417
 - bottom-up with mates, 416–417
 - bottom-up with skeleton, 418
 - in-context design, 418
 - master model, 421–422
 - mates, 416–417
 - multibody, 419–421
 - motion, dynamic, 872
 - parts, 429
 - layers, 812–813
 - modeling in place, 419
 - new, 606–607
 - Performance Evaluation tool, 651
 - populating, 126–127
 - PropertyManager, 126
 - reference geometry, 428
 - Reload tool, 653–654
 - SolidWorks Explorer, 425
 - SolidWorks Treehouse, 425–426
 - starting, 606
 - subassemblies, 433–434
 - from existing parts, 434–435
 - flexible, 435–436
 - mates, moving to, 650–651
 - parts, adding and removing, 649–650
 - process depiction, 437–438
 - purchased components, 437
 - relative motion, 437
 - Treehouse and, 649
 - Tree Display, 440–443
 - tutorial, 443–446
 - types, 416
 - virtual components, 428
 - Weld Beads, 1036–1038
- assembly configurations
- Advanced Component Selection, 594
 - best practices, 600
 - Configuration Publisher, 599–600
 - design tables, 599
 - Isolate function, 594
 - Modify Configuration interface, 599–600
 - parts
 - lightweight, 595
 - speed and, 593–594
 - performance and, 592
 - positions
 - mates and, 596–597
 - sketches and, 597–598
 - product variations and, 598–599
 - resolved, 595–596
 - SpeedPaks, 593, 595
 - suppression, 592–593
 - tutorial, 600–604
- assembly cuts, 550–552
- FeatureScope and, 552–554
- assembly drawings
- Broken-Out section view, 858
 - closed loop, 858–859
 - depth, 859
 - editing, 860
 - properties, 860
 - detached drawings, 861–862
 - Draft Quality views, 865–866
 - features, dimensioning, 845–846
 - lightweight drawings, 863
 - properties
 - assigning document driving, 846–847
 - linking notes to custom, 847
- Section view
- alignment, 856–857
 - hatching, 856–857
 - Isometric Sections, 856
 - parts, excluding, 855
 - SpeedPak and, 863–865
 - templates, multi-page, 847–849
 - tutorial, 866–868
 - views
 - alternate position, 849–850
 - color, 860–861
 - exploded, 850–854
- Assembly Drawings folder, 847
- assembly layouts, 499
- master model technique, 504–505
 - modeling, 614–615
 - sketches, 500–504
- assembly modeling *versus* multibody modeling, 872–873
- Assembly Performance Evaluation, 532
- assembly tree, history-based/non-history-based portions, 428–429
- AssemblyXpert, 532

- associative links
 - base parts, 24
 - derived parts, 24
 - inserted parts, 24
- associativity, 24
 - bidirectional, 24
- asymmetric fillets, 232, 240–241
 - profiles, 241–242
- asymmetrical chamfers, 254–255
- Auto Insert Dimension tool, 86
- Auto Relief feature, 956–957
- Auto Trace, 196
- Autodimension PropertyManager, 794–795
- autodimensioning, 794–795
- Automatic Relations setting, 90
- Automatic Solve setting, 90–91
- auto-transitioning, 69
- auxiliary views, 745
- axes, 94
- asymmetric fillets, profiles, 241–242

B

- balloons, 771–772
 - magnetic lines, 771–772
- Base Flange method, 949–950
 - Base Flange/Tab tool, 950–951
 - BaseBend features, 951
- base parts
 - associative links, 24
 - configurations, 354–355
- Baseline Dimension tool, 86
- baseline dimensions, 793–794
- Basic Motion, 669
 - chains, 698–700
 - contact, 696–697
 - gravity, 696–697
 - MotionManager, 670
 - motors, 697, 698–700
 - springs, 698–700
- Belt/Chain mate, 470–471
- Belt/Chain tool, 92
- Bend Allowance feature, 953
 - bend calculation tables, 955–956
 - Bend Deduction, 954–955
 - bend tables, 953–954
 - K-factor, 954
- bend calculation tables, 951–953
- Bend Radius feature, 953
- BibleInchTemplate.prt dot template, 99
- bidirectional associativity, 24
- Bill of Materials PropertyManager, 837
- BIM (building information model), 667
- black boxes, 878
- Block menus, 779–780
- Block PropertyManager, 775–776
- blocks, 725–726
 - creating, 778
 - Design library, 775
 - editing, 779
 - exploding, 779
 - inserting, 775–778
 - rebuilding, 779
 - sketch relations
 - adding, 777
 - definition, 777
 - editing, 778
 - existing, 776
 - layers, 778
 - leaders, 778
 - lock angle, 778
 - parameters, 778
 - text/dimension display, 778
- Blocks and Belts tutorial, 102–105
- Blocks toolbar
 - Add/Remove tool, 92
 - Belt/Chain tool, 92
 - Edit Block tool, 92
 - Explode Block tool, 92
 - Insert Block tool, 92
 - Make Block tool, 92
 - Rebuild Block tool, 92
 - Save Block/Save Sketch As Block tool, 92
- bodies
 - disjointed, connecting, 888
 - Feature Scope, 889–890
 - indents, 879–881
 - parasolids, 1051–1052
 - sharing, multibody modeling, 876–877
 - solid, patterns and, 293
 - surface, patterns and, 293
- Body folders, 895–897
- BOMs (Bills of Materials), 14
 - creating, manually, 821
 - default, 821
 - sample, 822
 - table-based
 - appearance, 827
 - columns, 828
 - combining indented, 827–828
 - configurations, 824–825
 - dissolving indented, 827–828
 - editing, 826–829
 - Excel-based, retiring, 829
 - indented lists, 827–828
 - item numbers, 826
 - Keep Missing Items, 825
 - numbering indented, 827–828
 - restructured indented, 827–828
 - rows, 828
 - table anchors, 823–824

- templates, 822–823
 - types, 824
 - Zero Quantity Display, 826
- tutorials, 837–840
- Boolean operations, multibody modeling and, 875
- Bottom Line
 - animation, 1145
 - annotations, 1147
 - assemblies
 - building, 1136–1137
 - configurations, 1142
 - drawings, 1150–1151
 - features, 1141–1142
 - sketches, 1139–1140
 - assemblies tools, 1140–1141
 - automation, 1145–1146
 - colors, 1149
 - dimensioning, 1148–1149
 - Direct Editing, 1161–1162
 - display states, 1142
 - drawing views, 1146–1147
 - drawings, 1129–1130, 1150
 - editing, 1135–1136, 1143–1144
 - equations, 1134
 - evaluating, 1135–1136, 1143–1144
 - Hole Wizard, 1141–1142
 - imported geometry, 1161–1162
 - interface navigation, 1127–1128
 - large scale design, 1144–1145
 - layers, 1149
 - layouts, 1139–1140
 - libraries, 1141–1142
 - line fonts, 1149
 - master modeling, 1153–1155
 - mates, 1137–1138
 - mirroring, 1133–1134, 1138–1139
 - modeling in context, 1143
 - Mold tools, 1165–1168
 - MotionManager, 1145
 - multibody modeling, 1151–1152
 - parts, 1129–1130
 - configurations, 1135
 - patterning, 1133–1134, 1138–1139
 - Plastic Features, 1162–1165
 - primary features, 1131–1132
 - reference geometry, 1129
 - secondary features, 1132–1133
 - sheet metal drawings, 1159–1160
 - sheet metal tools, 1155–1159
 - sketches, 1128–1131
 - surfaces, 1152–1153
 - symbols, 1147
 - tables, 1150
 - tolerancing, 1148–1149
 - troubleshooting, 1135–1136, 1143–1144

- visualization, 1130
 - weldment drawings, 1160–1161
 - weldments, 1160–1161
- bottom-up assembly, 422
- bottom-up modeling, 605
- Boundary feature, 223
 - lofts and, 224–225
 - profile arrangements, 225
- Boundary Surface feature, 911–912
- Boundary Surface PropertyManager, 912
- bounding boxes, 872
- bracket casting tutorial, 256–260
- Break view, 743–745
- bridges
 - multibody modeling and, 875
 - solids, multibody modeling, 887–888
- Broken category, 23
- Broken View PropertyManager, 745
- Broken-Out section view, 740–743, 858
 - closed loop, 858–859
 - closed loops, 741–742
 - depth, 743, 859
 - editing, 743, 860
 - properties, 860
 - Spline loop, 858–859
- .btl documents, 11

C

- CADKEY, 1049
- calloutformat.txt documents, 11
- Cam mate, 464–465
- camera, paths, 688–690
- Camera PropertyManager, 170, 171, 688–689
- Cameras (DisplayManager), 157, 165–166, 170
 - adding cameras, 171
 - Camera view, switching to, 172
 - positioning cameras, 171
- Cartoon tool, 152
- center creation, 67
- center marks, 780–781
 - patterns and, 781
- Centerline tool, 70
- centerlines, 201
 - dimensioning and, 189
- center-of-gravity, calculation, parts, 872
- centerpoint, 116
- Centerpoint Arc tool, 68–69
- Center-Radius circle, 69
- chain pattern, 492–494
- chamfer dimensions, 87
- Chamfer tool, Flip Direction option, 254–255
- chamfers, 135–137, 253–254
 - in assemblies, 554–555
 - asymmetrical, 254–255

- direct control, 254–255
 - indirect control, 254–255
 - switching to fillets, 255–256
- change, predicting, 112–113
- Change Display States tool, 153
- Check Entity dialog box, 390
- Check tool, 389–390
- Circle PropertyManager, 67–68
- Circle tool, 62
 - center creation, 67
 - perimeter creation, 68
 - Tangent to Three Entities, 68
 - Tangent to Two Entities, 68
- circles, Center-Radius, 69
- Circular pattern, 299–300, 484
 - tutorial, 310–311
- Circular Pattern PropertyManager, 289
- circular references, 427, 503
- Circular Sketch pattern, 288–289
- Circular Sketch Pattern tool, 80
- Clearance Verification, 520
- closed contour sketches, 220
- Closed Corner feature, 967–968
 - Break Corner, 969–970
 - Coplanar Faces, 969
 - Corner Trim, 969–970
 - Faces to Extend, 968
 - Faces to Match, 968
 - Gap, 968
 - Open Bend Region, 969
 - Overlap/Underlap Ratio, 968
- closed-loop sketches, 218
- Coincident mates, point-to-point, 459–460
- coincident sketch relation, 19
- Collision Detection, 525–526
- color
 - applying, 174
 - assembly drawings, 860–861
 - dimensions, driven, 792–793
 - interface, 47–48
 - lines, 198
 - tutorial, 208–211
- Color PropertyManager, 176
- Combine feature, 881–883
- Combine PropertyManager, 882–883
- CommandManager, 25–26
 - Annotations toolbar, 138
 - appearance, 29–30
 - Auto Collapse, 29
 - Customize mode, 27–28
 - docking, 28
 - Drawings toolbar, 138
 - Dual Monitors option, 36
 - Evaluate tab, 388
 - icons, 52
 - Instant2D, 83
 - limitations, 30
 - Sketch, 83
 - Sketch Ink toolbar, 97–98
 - Sketch toolbar, 64
 - tabs, 26, 27
 - document types and, 29
 - toolbars and, 29, 30
 - context toolbars, 32–33
 - flyouts, 32
 - Heads-Up View, 31
 - Shortcut (S), 33–34
 - Title Bar, 31–32
 - Widescreen option, 36
- Commands tab, 36
- complex parts, simplifying, 886–887
- complex shapes, multibody modeling, 877–878
- Component Line Font dialog box, 812–813
- component patterns, 432, 483
 - feature-driven, 491
 - local, 484
 - Instances to Skip option, 485
 - pattern references, 484
 - Pattern Seed only, 486
 - tutorial, 495–497
- components
 - Isolate tool, 653
 - LDR and, 660
 - mates, listing, 639
 - replacing, 647–649
 - selecting, 528–532
 - Advance Select options, 531
 - hidden components, 530
 - identical components, 530
 - internal components, 530
 - parts mated to others, 530
 - by size, 532
 - subassemblies, 530
 - suppressed components, 530
 - toolbox parts, 530
 - Volume Select, 529
 - virtual, 607–608
 - saving, 609
- Components to Explode, 850–851
- compositive curves, 266–267
- Concentric mates, exploded views and, 850
- Configuration Publisher, 364–366
- ConfigurationManager, 26, 336–337
 - Display States interface, 163–164
- configurations, 335
 - activating, 339–340
 - animation and, 671
 - color, 342
 - creating, 341–344
 - deleting, 337–338
 - derived, 347–348
 - descriptions, 341–342

- dimension control, 350
 - dimension modification, 343
 - dimensions, negative, 344
 - display states and, 590
 - feature suppression, 342
 - file size, speed and, 348–350
 - library features, 355
 - mate suppression, 342
 - Modify Configurations dialog box, 344–346
 - options, 341–342
 - parts, 336
 - base, 354–355
 - derived, 354–355
 - inserted, 354–355
 - planes, 353–354
 - properties, 341–342, 346
 - custom, 346–347
 - controlling, 351–352
 - purging data, 349
 - rebuilding, 342–343
 - relations, controlling, 352–353
 - saving data, 349
 - sorting
 - alphabetization, 338
 - naming configs, 338–339
 - suppression control, 350–351
 - Table Views, 345
 - tutorials, 365–368
- Confirmation Corner, 26, 63
 - Conic radius fillet, 242
 - Conic rho fillet, 242
 - conics, 77–78
 - Constant Pitch helix, 262
 - constant-size fillet, 232
 - creating, 233–234
 - constant-width fillets, 249–250
 - construction geometry, 72, 201
 - Construction Geometry tool, 75
 - construction lines, 70, 201
 - consumed features, Rollback Bar and, 372
 - context bar, 26, 63
 - context toolbars, 32–33
 - contexts, multiple, 606
 - continuous curvature fillets, 242–243, 249
 - contour selection, 121–122
 - Revolve feature, 223
 - Convert Entities tool, 72, 262
 - Offset Entities command, 72–73
 - coordinate systems, 94–96
 - reference geometry and, 93
 - Coordinate triad, 26
 - Copy Appearance tool, 152
 - Copy Entities tool, 191
 - Copy tool, 76
 - core features, 1109
 - Corner Rectangle tool, 66
 - Corner Relief feature, 970–971
 - cosmetic patterns, 307–308
 - tutorial, 313–314
 - Crop Views, 740
 - cursors
 - changing, 38
 - sketch cursor, 38
 - curvature
 - continuous, fillets, 249
 - Gaussian curvature, 909
 - tangents, 919
 - Zebra Stripes tool, 153–154
 - Curve Through Reference Points feature, 266
 - Curve Through XYZ Points feature, 265–266
 - Curved Slot tool, 82
 - Curve-Driven pattern, 300–302
 - curves, 261
 - composite, 266–267
 - conics, 77–78
 - Convert Entities tool, 262
 - ellipses, 77
 - equation driven, 267
 - Helix, 262
 - pitch, 262
 - lighting, 170
 - parabola, 77
 - projected, 264
 - sketch on face, 265
 - sketch on sketch, 265
 - Projected, 262
 - sweeps, 227–228
 - Curves toolbar, 262
 - custom drafting standards, 706–707
 - Custom Properties tab, 347
 - custom units, 26
 - customization
 - interface
 - hotkeys and, 49–52
 - icons, 52
 - saving settings, 54–55
 - mouse gestures, 51
 - Customize dialog box, 36
 - Customize Menu, 37
 - cut-lists
 - items, 872
 - properties, 872
 - cuts, multibody modeling, 876

D

- daisy chaining, 427, 503
- Dangling category, 22
- dangling sketches, 20
- data import, 1049–1050
- Data Migration tab, 1050–1051

- data transfer, IFC (Industry Foundation Classes) file
 - type, 667–668
- Deboss feature, 272–273
- Decals (DisplayManager), 157, 165
- Default Templates option, 14
- Defeature, 533–534
- Defined in Context category, 23
- Deform feature, 275–277
- degenerate geometry, 908
- degree of freedom, 459–460
- Delete Body command, 872
- derived configurations, 347–348
- derived parts
 - associative links, 24
 - configurations, 354–355
- derived sketches, 193
- design
 - assemblies
 - base parts, 416–417
 - bottom-up with mates, 416–417
 - bottom-up with skeleton, 418
 - in-context design, 418
 - mates, 416–417
 - documents
 - .sldasm, 10
 - .slddrw, 10
 - .sldprt, 10
 - intent, 19
 - top-down, 185
- design intent, 20, 111–112
 - change prediction, 112–113
 - editing
 - Display/Delete Relations tool, 22–23
 - sketch relations, 22
 - functional features, 112
 - primary features, 112
 - symmetry, 112
- Design Library, 537–543
 - annotations, 541
 - blocks, 775
 - display modes, 546
 - folder location, 542
 - library parts, 542–543
 - Task pane, 538
 - thumbnail size, 546–548
- design tables, 355–356, 830–832
 - assembly configurations, 599
 - creating, 357–362
 - dimensions, suppressed, 356
 - editing, 364
 - items driven by, 356–357
 - planes, configuration, 356
 - relations, suppressed, 356
 - settings, editing, 362–363
 - tutorials, 365–368
- design trees
 - FeatureManager, 18
 - MotionManager, 671
- Detach Segment on Drag setting, 91
- detached drawings, assembly drawings and, 863
- Detached PropertyManager, 26
- Detail View
 - activated drawing views, 734–735
 - detail circles, 735
 - editing, 735–736
 - Locked Focus, 735
- developable surfaces, 908
- devices, 52–53
 - touchscreen support, 53–54
- dialog boxes
 - Add Relations, 71
 - Check Entity, 390
 - Component Line Font, 812–813
 - Dimension, 329
 - Equation Export, 330
 - Equations, 317–318, 322
 - External References, 937
 - Grid Components, 666–667
 - Keyboard, 50–51
 - Layers, 811
 - Link to Property, 847
 - Modify, 343
 - Modify Configurations, 344–346
 - Modify Sketch, 191–192
 - New SolidWorks Document, 8, 99
 - Open, 56
 - Page Setup, 792–793
 - Save As, 646
 - Save As with References, 646
 - Sheet Properties, 137, 846–847
 - SketchXpert, 188
 - Specify Configurations, 343
 - Summary Information, 711
 - Systems Options Colors, 47–48
 - View Orientation, 154–156
 - Welcome to SolidWorks, 7
- Dimension dialog boxes, 329
- Dimension palette, 798–799
 - alignment and, 803–804
- Dimension PropertyManager, 84, 318–319, 791
 - Angle option, 84–85
 - Arc Length option, 85
 - Diameter option, 84
 - Dimension palette, 798–799
 - Dimension Text, 795–796
 - display options, 796–797
 - Primary Value Override, 796
 - Radial option, 84
- Dimension Text panel, 795–796
- dimensions. *See also* Smart Dimension tool
 - 3D sketches, 204
 - weldments and, 1021–1022
 - alignment, 802–803
 - automatic, 804
 - grid snapping, 803
 - inference, 803

- animation and, 671
 - arranging automatically, 804
 - assembly features, 845–846
 - baseline, 86
 - break lines, 798
 - centerlines and, 189
 - chamfer, 87
 - controlling with configurations, 350
 - design tables, 356
 - dimension text, 795–796
 - direct, 124–125
 - display options, 796–797
 - driven, 787–788
 - color, 792–793
 - equations, 323–325
 - equations
 - driven, 323–325
 - Modify dimension box, 327–328
 - formatting, 798–799
 - horizontal, 86
 - inserting automatically, 86
 - Instant2D, 83
 - layers, 811
 - library features, 550
 - Model Items PropertyManager, 788–790
 - modification, 343
 - naming, equations, 318–320
 - negative, 344
 - numeric input, 189
 - ordinate, 86–87
 - parts, 322
 - placing, Insert Model Items, 787–788
 - primary value override, 796
 - Rapid Dimension manipulator wheel, 791
 - reference dimensions, 790–791
 - Annotation views, 792
 - autodimensioning, 794–795
 - baseline, 793–794
 - DimXpert and, 791–792
 - ordinate, 793–794
 - reference sketches, 795
 - styles, 802
 - symbols and, 779
 - thickness, 218
 - tolerances, 799–800
 - Fit tolerances, 800
 - Geometric Tolerancing symbols, 801–802
 - precision values, 801
 - tutorials, 805–808
 - tutorials, 805–808
 - vertical, 86
 - witness lines, 798
- Dimensions/Relations toolbar
- Add Relations tool, 89
 - Auto Insert Dimension tool, 86
 - Baseline Dimension tool, 86
 - Horizontal Dimension tool, 86
 - Isolate Changed Dimensions tool, 89
 - Ordinate Dimension tool, 86
 - Scan Equal tool, 89
 - Smart Dimension tool, 86
 - Vertical Dimension tool, 86
- DimXpert Manager, 26
- reference dimensions and, 791–792
- direct dimensions, 124–125
- Direct Editing tools, 1060–1063
- history and, 1064–1067
 - Move Face feature, 1063–1064
- Display pane, 26, 173
- display states, 590–592
- configurations and, 590
 - drawings and, 592
 - parts, 592
- Display States, appearances, 163
- display tools, 816–818
- Display Warnings option, 186
- Display /Delete Relations dialog box
- All in this Sketch, 185
 - Dangling, 185
 - Defined in Context, 185
 - External, 185
 - Locked (Broken), 185
 - Overdefining/Notsolved, 185
 - Selected Entities, 185
- Display /Delete Relations Property Manager, 23, 184, 205
- Display /Delete Relations tool, 22–23
- Quick Snaps flyout, 72
- DisplayManager, 26, 45, 129
- Appearances, 157
 - Cameras, 157, 165–166, 170–173
 - Decals, 157, 165
 - Lights, 157, 165–166, 169–170
 - RealView, 173
 - Scenes, 157, 165–169
 - Task pane
 - Appearances, Scenes, and Decals, 43
 - Custom Properties, 43
 - Design Library, 43
 - File Explorer, 43
 - Home tab, 43
 - Recovered Documents, 43
 - SolidWorks Forum, 43
 - View Palette, 43
 - walk-throughs, 662
- Document origin, 26
- Document Properties dialog box, 14
- Document Property setting, 14
- documents
- assemblies, 8
 - .btl, 11
 - calloutformat.txt, 11
 - design
 - .sldasm, 10
 - .slddrw, 10
 - .sldprt, 10
 - drawings, 8

- driving assembly properties, 846–847
- library files
 - .sldblk, 10
 - .sldlfp, 10
- multiple windows, 55
- new, 8–9
- open, cycling through, 56
- parts, 8
- recent, 56–58
- Recent, 56–58
- .sldclr, 11
- .sldmat, 11
- .sldreg, 11
- .sldstd, 11
- styles
 - .sldgtolfvt, 10
 - .sldsfvt, 10
 - .sldweldfvt, 10
- .swb, 11
- .swp, 11
- symbol files
 - gtol.sym, 11
 - swlines.lin, 11
- templates and formats
 - .asmdot, 10
 - .asmprp, 10
 - .drwdot, 10
 - .drwprp, 10
 - journal.doc, 10
 - .prt-dot, 10
 - .prtprp, 10
 - .sldbombt, 10
 - .slddrt, 10
 - .sldholtbt, 10
 - .sldrevtbt, 10
 - .sldtbt, 10
 - .sldwldtbt, 10
 - .xls, 10
- .txt, 11
- .xls, 11
- Dome feature, 269–271
- double hold-line fillets, 249
- doubly nested contour sketches, 220
- Draft, Undercut, and Parting Line Analysis tool, 152
- Draft Analysis tool
 - Basic, 1094
 - Face Classification, 1096–1097
 - Gradual Transition, 1095–1096
 - steep faces, 1097
 - workflow, 1098
- Draft feature, 1083–1084
 - draft limitations, 1086
 - DraftXpert, 1087
 - failure, 1086–1087
 - Neutral Plane draft, 1084
 - Parting Lane draft, 1084–1985
 - Step draft, 1085–1086
- Draft Quality views, 865–866
- Drafting Standard setting, 9
- drafting standards
 - custom, 706–707
 - templates, 8
- DraftSight, 809
- dragging entities, 192, 516–517
 - Along Assembly XYZ, 517
 - Along Entity, 517
 - By Delta XYZ, 517–518
 - Use For Positioning Only Option, 513–514
- Drawing View PropertyManager, 138
- drawings, 8
 - blocks, 725–726
 - creating, 128
 - display states and, 592
 - drafting standards, 706–707
 - FeatureManager, 862
 - formats, 705–707
 - creating, 707–720
 - editing, 708–709
 - files, 716–717
 - maintaining, 706
 - properties, 710–715
 - saving, 717–718
 - second sheet, 718–720
 - Sheet Format tools, 707
 - sheet formats, 705
 - templates, 705
 - text, 710
 - text boxes, 709–710
 - title blocks, 715
 - Hole Wizard, 132–133
 - saving, as detached, 862
 - sheet metal drawings, 1005–1006
 - Sheet Properties dialog box, 137
 - sketch techniques, 130–132
 - SpeedPak and, 433
 - tabulated, 830–832
 - templates, 128, 705–706
 - blocks in, 724–725
 - maintaining, 706
 - predefined views, 720–724
 - properties, 725
 - saving, 725
 - styles in, 724–725
 - tutorial, 137–141
- Drawings toolbar, 138
 - Alternate Position, 849–850
- driven dimensions, 787–788
 - color, 792–793
- drop-down menus, 37
- DRV (Dynamic Reference Visualization), 40, 372
- DWG/DXF, saving views to, 748

Dynamic Assembly Motion, 459
 Dynamic Clearance, 523–525
 Dynamic Mirror command, 80, 290
 dynamic motion, 672
 assemblies, 872

E

Edge Flange feature
 Angle panel, 961
 curved edges, 962–963
 default radius, 960
 Edit Flange Profile button, 959–960
 Flange Length, 961
 Flange Position, 962
 Gap Distance, 960–961
 Trim Side Bends, 962

edges, 174
 filleting, 187
 hiding/showing, 815–816
 sharp, 196
 tangent, 754–756

Edit Appearance tool, 152
 Edit Block tool, 92
 Edit Scene PropertyManager, 145

editing. *See also* Direct Editing tools
 Broken-Out section view, 743
 Detail Views, 735–736
 formats, 708–709
 mates, 642–645
 existing, 471–473
 Section Views, 739
 Smart Components, 575–576
 tutorials, 406–412

ellipse, 77
 ellipsis button (. . .), 728
 Emboss feature, 272
 Emboss PropertyManager, 272
 empty views, 747
 Enable On-Screen Numeric Input, 65
 Enable Snapping setting, 91
 end conditions
 Extrude feature, 221
 Revolve feature, 222

entities
 copying, 191
 pasting, 192
 deleting, relations and, 184
 dragging, 192
 fillets and, 236
 in lofts, 226
 Mated Entities, 642
 moving, 190
 pasting, 192
 reference entities, 462
 replacing, 186–187
 rotating, 190
 scaling, 191

envelopes, 560–562
 Equal sketch relation, 116
 Equation Driven Curve PropertyManager, 82
 Equation Driven Curve tool, 81–82
 equation driven curves, 267
 Equation Editor, 327
 Equation Export dialog box, 330
 equations, 317
 building, 320–322
 comments, 323
 creation, 318–323
 dimensions
 driven dimensions, 323–325
 Modify dimension box, 327–328
 naming, 318–320
 expressions, Dimension dialog boxes, 329
 external
 assemblies, 424
 linking to, 330
 IF statements, 325–326
 tutorial, 330–332
 variables, global, 326–327, 424

Equations dialog box, 317–318, 322
 Equations interface, 317
 Dimension View, 318
 Equation View, 318
 Ordered View, 318
 Sketch Equation View, 318

errors *versus* warnings, 638
 Evaluate tab, 388
 evaluation techniques, 387–388
 Check tool, 389–390
 geometry
 Curvature Comb, 395–396
 curvature display, 391, 392
 Deviation Analysis, 391–393
 Geometry Analysis tool, 394–395
 Performance Evaluation tool, 395
 RealView, 391
 Tangent Edges as Phantom settings, 393–394
 Zebra stripes, 390–391
 tutorials, 406–412
 Verification on Rebuild, 388–389

Excel tables *versus* SolidWorks, 821–822
 Explode Animation Wizard, 677–678
 Explode Block tool, 92
 Explode command, 851–852
 Explode Directions box, 850–851
 explode lines, 853
 Exploded View, 670, 854–855
 exploded views
 animation, 677–678
 assemblies, 850–854
 expression equations, Dimension dialog boxes, 329

- Extend Surface tool, 916–917
- Extend tool, 79, 909
- External category, 23
- external equations, linking to, 330
- External References dialog box, 937
- Extrude feature, 113, 116, 217–218
 - from 3D sketches, 220
 - end conditions, 221
 - Blind, 118
 - Offset from Surface, 118–119
 - Through All, 120
 - Up to Next, 120
 - Up to Surface, 118
 - Up to Vertex, 118
 - from selection, 116–118
 - Thin Feature panel, 120–121
 - workflow, 219
- Extrude PropertyManager, 120–121, 876
- Extrude tool, 909–910
- Extruded Boss feature, 218
- Extruded Cut tool, 129
- Extruded Surface PropertyManager, 909–910
- extruded surfaces, 909–910
- extruding, loops, multibody modeling, 875

F

- Face Curves tool, 79, 908
- Face fillets, 232, 246–247
 - Help Point, 247, 248
- FEA (Finite Element Analysis), 347–348
- Feature Scope, 889–890
- Feature toolbar, Extruded Cut, 129
- feature-based modeling, 15–16
- feature-driven component patterns, 491
- FeatureManager, 15, 26, 38
 - Annotations folder, 156
 - assemblies, 126
 - design trees, 18
 - detachable, 380–381
 - Display pane, 173
 - displaying, 381
 - DRV (Dynamic Reference Visualization) and, 40
 - flyout, 44, 380–381
 - folders, 42
 - interface
 - Appearances, 39
 - collapse tab, 39
 - ConfigurationManager, 39
 - DimXpertManager, 39
 - Display Mode, 39
 - Display pane, 40
 - Display Pane Splitter, 39
 - DisplayManager, 39
 - Feature folder, 39
 - FeatureManager Filter, 39, 41
 - FeatureManager panel splitter bar, 39
 - features, 39
 - Freeze Bar, 39
 - Freeze bars, 40–41
 - Hide/Show, 39
 - Metadata folders, 39
 - PropertyManager, 39
 - Reference Geometry, 39
 - Rollback bar, 40–41
 - Rollback Bar, 39
 - splitter bar, 40
 - Transparency, 39
- Material folder, 159–160
- parts, new, 62
- Pen Sketch entry, 98
- PropertyManager split screen, 40
- Sensors, 199–200
- sketch pictures, 81
- split, 44
- symbols, 651–652
- tabs, 26
- toggling, 36
- tutorial, 446–447
- FeatureManager Filter, dimension names, 320
- features
 - assemblies, applying, 430–431
 - mates and, 639–640
 - ordering, 378–379
 - reordering, 883
- file management
 - Pack and Go, 645, 646–647
 - PDM (product data management), 645
 - Replace Components tool, 647–649
 - Save As tool, 645
 - Save Copy tool, 645
 - Save tool, 645
- files
 - configurations, speed, 348–350
 - DWG/DXF, 716–717
 - searching for, 47
 - Smart Components, 574–575
- Fill pattern, 303–304
- Fill Surface tool, 918–920
- Fill tool, 909
- Fillet Bead tool, 558–560
- Fillet feature, 231
- Fillet PropertyManager, 135, 232–233
 - Keep Edge/Keep Surface toggle, 239
 - Keep Feature, 239–240
 - Multiple Radius Fillet option, 238
 - Round Corners option, 239
 - Selection toolbar, 236
 - Variable Radius Parameters panel, 244
- Fillet tool, 909
- fillets, 70, 135–137, 231
 - in assemblies, 554–555
 - asymmetric, 240–242

- constant-size, 232
 - creating, 233–234
- constant-width, 249–250
- continuous curvature, 242–243, 249
- double hold-line, 249
- edges, 187
- entity selection, 236
- Face, 232, 246–247
 - Help Point, 247
- folders, 237
- full round, 232, 250–251
- hold line, 267
- large number, 236
- multiple sizes, 238–239
- patterning, 295
- preview, 236–237
- setback, 232
- setback with variable radius, 232
- single hold-line, 247–249
- switching to chamfers, 255–256
- symmetric, 240–242
- Tangent Propagation option, 235
- variable-radius
 - transitions, 245
 - uses, 245
 - values, 243–245
- variable-size, 232
- FilletXpert, 236
- FilletXpert PropertyManager, 236
- filters
 - FeatureManager, 41
 - MotionManager, 671
- Fit Text Button, 767
- Fit tolerances, 800
- fixtures, 845–846
- Flat Pattern feature, 957
 - Convert Entities, 958
 - Corner Treatment option, 958
 - Fixed Face parameter, 958
 - suppressed, 957
- Flex feature, 273–275
 - multibody modeling, 883–884
- flexibility, parts, 682
- Flip Direction option, chamfers, 254–255
- floors
 - orientation, 145
 - position, 145
- Flyout FeatureManager, 177
- flyouts, 32, 35–36
 - FeatureManager, 44
 - Quick Snaps, 72
- folders
 - assemblies, 438–439
 - creating, 439–440
 - Assembly Drawings, 847
 - Design Library, 542
 - FeatureManager, 42

- libraries, adding, 550
- Mates, 637–638
- naming, 380
- ordering, 379–380
- fonts
 - notes, 772–773
 - OLF SimpleSansOC, 766
 - stick fonts, 196
 - TrueType fonts, 196–197
- footprints, 974
- Format Painter, 774
- formats, 705, 707
 - editing, 708–709
 - files, DWG/DXF, 716–717
 - Format Painter, 774
 - maintaining, 706
 - properties, 710–711
 - custom data, 711
 - Custom Properties tab, 711–712
 - error display, 713–714
 - link variables, 713–714
 - linked, 714–715
 - links, 712–713
 - Summary Information dialog
 - box, 711
 - saving, 717–718
- second sheet
 - adding sheets, 718–719
 - reloading formats, 719–720
- Sheet Format tools, 707
- sheet formats, 705
 - layers, 810–811
- templates, 705
 - assembly drawings, 847–848
- text, image placement, 710
- text boxes, 709–710
- title blocks, 715
- Formatting toolbar, 766
- Free Drag, 516–617
- free motion, 672
- full round fillet, 232, 250–251
- Fully Define Sketch tool, 87–88, 287, 795
- fully defined sketches, 20
- functional features, 112

G

- gauge tables, 951–953
- Gaussian curvature, 909
- Gear mate, 466
- general tables, 836
- Geometric Tolerancing symbols, 801–802
- geometry. *See also* imported geometry
 - appearance overrides and, 590–591
 - calculators, 212–214
 - construction geometry, 72, 201
 - degenerate, 908

- multibody modeling and, 875
 - parts, 608
 - reference geometry, 62, 93
 - assemblies, 428
- geometry evaluation
 - Curvature Comb, 395–396
 - curvature display, 391, 392
 - Deviation Analysis, 391–393
 - Geometry Analysis tool, 394–395
 - Performance Evaluation tool, 395
 - RealView, 391
 - Tangent Edges as Phantom settings, 393–394
 - Zebra stripes, 390–391
- Geometry Pattern, 284–286, 292–293
- Gestures donut, 26
- ghost graphics, 865
- ghosts, 432–433
- global shape modeling, 275–277
- global variables, 326–327, 424
- graphics, ghost graphics, 865
- graphics window
 - scrollbars, 147–148
 - splitters, 147–148
- grid, 63
- Grid Components dialog box, 666–667
- grid snapping, 803
- Grid/Snap tool, 77
- GridSystem, 663–664
 - Grid Components dialog box, 666–667
 - output, 665–666
 - sketches, 664–665
- GridSystem PropertyManager, 665

H

- Heads-Up View toolbar, 26, 31, 143–144
- Helix curve, 262
 - Constant Pitch, 262
 - pitch, 262
 - taper, spirals, 264
 - Variable Pitch, 262
 - workflow, 264
- Helix PropertyManager, Taper Helix panel, 262
- Helix/Spiral PropertyManager, 263
- Help
 - contents, 1170
 - graphics cards, 1170
 - Search, 1170
 - Web Help, 1169
- Help menu
 - Activation options, 6–7
 - What's New, 7–8
- Help Point, Face fillets, 247, 248
- Hem feature, 964–965
- Hidden Lines Removed (HLR), 151, 811

- Hidden Lines Visible (HLV), 151, 811
- Hide All Types tool, 153
- Hinge mate, 470
- history-based modeling, 16–18
- hold lines
 - fillets and, 247–249
 - split lines and, 267
- Hole Alignment tool, 534–535
- Hole Series interface, 556–558
- hole tables, 832–834
 - tutorials, 840–842
- Hole Wizard, 19, 132–133, 555–558, 832–834
- Horizontal Dimension tool, 86
- horizontal modeling, 386
- hotkeys
 - customization and, 49–52
 - Keyboard dialog box, 50–51
 - macros and, 54
- hybrid modeling, 907–908
- hyperlinks, text, 775

I

- IAI (International Alliance for Interoperability), 667
- icons, 52
 - CommandManager, 52
- IF statement
 - in equations, 325–326
 - suppression states, 329
- IFC (Industry Foundation Classes) file type, 667–668
- IGES (Initial Graphics Exchange Specification), 1049
- image placement, text and, 710
- imported geometry, 1049–1051
 - 3D Interconnect, 1051–1052
 - data
 - cloud point, converting, 1060
 - ensuring good, 1059–1060
 - errors, 1057
 - manual repair, 1058–1059
 - repairing, 1057–1058
 - Import Diagnostics, 1058
 - import results, 1052
 - imports, data imports, 1052–1057
 - tasks, 1050–1051
 - tutorial, 1067–1068
- in-context design, 419
- in-context modeling, 608–609
 - advantages, 613
 - assembly layout modeling, 614–615
 - best practices, 623–624
 - configurations and, 625–626
 - design intent, 630
 - Edit Component button, 618–620

- external references, 620–623, 630
 - mirror parts, 631
 - split parts and, 631
 - file management and, 627
 - instances, multiple, 627
 - layouts, 628
 - in libraries, 629
 - mates and, 627
 - versus* mating, 630
 - motion and, 626–627
 - multibody modeling, 614
 - multiple contexts, 624–625
 - parts
 - color, 617–618
 - transparency, 617–618
 - problems, 613–614
 - process
 - InPlace mate, 616
 - relations, 617
 - starting, 615–616
 - references, 611–613
 - circular, 627–628
 - relations, removing, 629–630
 - skeletons, 628
 - text color, 617
 - tutorial, 631–635
 - virtual components, 607–608
- in-context references, editing driving part, 611–613
 - in-context relations, 427
 - Indent feature, 277–279, 879–881, 1087–1088
 - Indent PropertyManager, 880–881
 - inferencing, 89–90
 - alignment, 803
 - inflection point, 71
 - in-place modeling, 605
 - update holders, 606
 - Input Dimension Value function, 66
 - Insert Block tool, 92
 - Insert Component PropertyManager, 561
 - Insert Into New Part tool, 934, 938
 - Insert Line option
 - Angle option, 66
 - Horizontal option, 65
 - Infinite Length option, 66
 - Vertical option, 65
 - Insert menu, 37
 - Insert Model Items, 787–788
 - Insert Part feature, 892–893
 - Insert Part PropertyManager, 893, 935
 - Insert Part tool, 934, 935–937
 - inserted parts
 - associative links, 24
 - configurations, 354–355
 - installation, 3
 - reinstallation, 11
 - Installation Manager, 5
 - Instant 2D, 83
 - Instant 3D, 122–123, 221
 - interfaces
 - Advanced, 12
 - Application window controls, 26
 - background options, 48–49
 - color, 47–48
 - CommandManager, 25–26
 - tabs, 26
 - ConfigurationManager, 26
 - Confirmation corner, 26
 - context bar, 26
 - Coordinate triad, 26
 - custom units, 26
 - customization
 - hotkeys and, 49–52
 - icons, 52
 - saving settings, 54–55
 - Detached PropertyManager, 26
 - Dimension Properties, 84–85
 - DimXpert Manager, 26
 - Display pane, 26
 - DisplayManager, 26
 - Document origin, 26
 - Dual Monitors, 36
 - Equations, 317–318
 - FeatureManager, 26
 - Appearances, 39
 - collapse tab, 39
 - ConfigurationManager, 39
 - DimXpertManager, 39
 - Display Mode, 39
 - Display pane, 40
 - Display Pane Splitter, 39
 - DisplayManager, 39
 - Feature folder, 39
 - FeatureManager Filter, 39, 41
 - FeatureManager panel splitter bar, 39
 - features, 39
 - Freeze Bar, 39
 - Freeze bars, 40–41
 - Hide/Show, 39
 - Metadata folders, 39
 - PropertyManager, 39
 - Reference Geometry, 39
 - Rollback bar, 40–41
 - Rollback Bar, 39
 - splitter bar, 40
 - tabs, 26
 - Transparency, 39
 - Full Screen mode, 36
 - Gestures donut, 26
 - Heads Up View Toolbar, 26
 - Hole Series, 556–558
 - library features, 538

- Mode tabs, 26
- Novice, 12
- Offset Entities, 72
- PropertyManager, 26
- RMB menu, 26
- Rollback bar, 26
- "S" menu, 26
- Selection breadcrumb, 26
- SolidWorks login, 26
- tags, 26
- Task bar, 26
- task pane, 26
- Title Bar, 26
- Title Bar menu, 26
- Title Bar Toolbar, 26
- Touch Mode, 32
- Trim, 73
- View indicator, 26
- Widescreen, 36
- Window expander, 26
- Interference Detection, 521
 - Component View, 522
 - ignoring interference, 522
 - results display, 522
- interpolated features
 - Boundary, 223
 - Loft, 223
 - Sweep, 223
- Intersect feature, 279
- Intersect tool, 923–924
- Intersection Curve tool, 78
- Inventor, 1049
- ISO standards, 8
- Isolate Changed Dimensions, 89
- Isolate tool, 653
- Isometric view, 138
- isoparameter lines, 908

J

- Jog feature, 965–966
 - Fixed Face, 965–966
 - Fixed Projected Length, 966–967
 - Jog Angle, 967
 - Jog Offset, 966
 - Jog Position, 967
- Jogged Leader icon, 771
- jogged leaders in notes, 771

K

- keyboard
 - Alt-key combinations, 51–52
 - arrow keys, 144
- Keyboard dialog box, 50–51
- kinematic motion, 672

- Knit function, 906
- Knit Surface tool, 915

L

- large assemblies, LDR (Large Design Review), 657–659
 - Snapshots, 660–661
 - updating, 660
- Layer toolbar, 811
- layers
 - 2D data, imported, 809–810
 - components
 - assembly colors, 811–812
 - assembly parts, 812–813
 - dimensions, 811
 - notes, 811
 - sheet formats, 810–811
 - views, 752–753
- Layers dialog box, 811
- Layout feature, 499, 504
 - 3D sketches, 505
 - advantages, 507
 - limitations, 507
 - virtual components, 506
 - workflow, 505–506
- layout sketches, assemblies, 426–427
- layouts, 499
 - assembly layouts, 499, 500
 - daisy chaining, 503
 - master model technique, 504–505
 - workflow, 501
 - tutorial, 507–512
- LDR (Large Design Review), 657–659
 - components, 660
 - Snapshots and, 660–661
 - updating, 660
- leaders, notes
 - adding, 770
 - jogged, 771
 - multiple, 770
 - placing, 769–770
- Learn tab (Welcome dialog), 7
- Library Feature PropertyManager, 540
- library features, 537–543
 - assemblies, 543
 - configurations, 355
 - creating, 543–544
 - from parts, 548–550
 - dimensions, 550
 - folders, adding, 550
 - interface, 538
 - limitations, 544
 - routing, 543
 - saving, 545–546
 - Task pane, 538

- thumbnail display, 546–548
- tutorials, 579–586
- library file documents
 - .sldbkl, 10
 - .sldlfp, 10
- library parts, reusing, 872
- license agreement, 6
- lighting, 169–170
- Lights (DisplayManager), 157, 165–166, 169–170
- lightweight drawings, assembly drawings and, 863
- limit mates, 466–468
- line font, 813
- line format, 813
 - color display mode, 815
 - end cap style, 814
 - Line Format settings, 814
 - line style, 815
 - line thickness, 814–815
- Line Format toolbar, 813–815
- Line Style tool, 198–199
- Line Thickness tool, 198–199
- Line tool, 62, 65
- Linear Coupler mate, 470
- Linear Note Pattern PropertyManager, 767–769
- Linear pattern
 - instances, 296
 - increments, 298–299
 - modified, 299
 - skipping, 297
 - varying, 298
 - spacing, 296
 - Vary Sketch option, 297
 - visual properties, 297
- Linear Pattern PropertyManager, 288
- Linear Sketch pattern, 287–288
- Linear Sketch Pattern tool, 80
- lines
 - color, 198
 - construction lines, 70
 - creating, 65–66
 - explode lines, 853
 - isoparameter lines, 908
 - split lines, 267
 - style, 198–199
 - thickness, 198–199
- Link to Property dialog box, 847
- linking
 - to external equations, 330
 - notes to custom properties, 847
 - properties, 712–715
 - notes, 774–775
 - variables, 713–714
- local component patterns, 484
 - Instances to Skip option, 485
 - pattern references, 484
 - Pattern Seed only, 486

- local operations, multibody modeling
 - Flex feature, 883–884
 - Shell feature, 884–885
- Locked category, 23
- Locked mates, 516
- Loft feature, 223
 - Boundary comparison, 224–225
 - interpolation and, 223
 - spline comparison, 226–227
 - transitions, 224
- Loft PropertyManager, 226
- Loft tool, 909
- lofts, entities in, 226
- loops, extruding, multiple, 875

M

- machined parts, 113
- macros
 - hotkey access, 54
 - mates and, 458
- magnetic lines, balloon alignment, 771–772
- Magnifying Glass, 148
- Make Block tool, 92
- Make Path function, 80
- master model, 421–422, 933
 - child relationships, 933–934
 - Insert Into New Part tool, 934
 - Insert Part tool, 934
 - parent relationships, 933–934
 - Pull functions, 934–935
 - Insert Into New Part feature, 938
 - Insert Part feature, 935–937
 - Push functions, 934–935, 938–939
 - Save Bodies feature, 940–941
 - Split feature, 939–940
 - Save Bodies tool, 934
 - Split tool, 934
 - tutorials, techniques, 941–945
- Master Model workflow, 878
- master models, 504
- Mate Controller, 670, 700–702
- Mate PropertyManager, 450, 513, 642–645
 - Copy with Mates, 457–458
 - editing mates, 642–645
 - faces, hiding, 452–453
 - macros, 458
 - Multiple Mate mode, 453–454
 - Select Other command, 452
 - workflow, 450–451
- Mated Entities PropertyManager, 642, 644
- Material folder (FeatureManager), 159–160
- materials
 - adding, 113
 - editing, 159–160
 - removing, 113

- mates, 127–128
 - Advanced and Mechanical, 462
 - animation, 682–683
 - applying, 449–450
 - assemblies, Mates folder, 638
 - Belt/Chain mate, 470–471
 - best practices, 475–476
 - Cam mate, 464–465
 - Coincident, point-to-point, 459–460
 - Component Preview window, 457
 - Copy with Mates, 457–458
 - displaying, without features, 639–640
 - editing, 642–645
 - existing, 471–473
 - faces, hiding, 452–453
 - Gear mate, 466
 - Hinge mate, 470
 - limit mates, 466–468
 - Linear Coupler mate, 470
 - listing, components, 639
 - Locked, 516
 - macros and, 458
 - models, position, 451
 - Multiple Mate mode, 453–454
 - options, 474–475
 - organization, 429–430
 - Path mate, 468–469
 - Peg-in-Hole mate, 455
 - Profile Center mate, 463
 - Rack and Pinion mate, 466
 - references, 93
 - Replace Mate Entities tool, 642, 644
 - Screw mate, 468
 - Select Other command, 452
 - SmartMates, 454
 - alt+dragging, 454–456
 - dragging between windows, 456
 - mate references, 456
 - subassemblies, 650–651
 - Symmetric mate, 463–464
 - troubleshooting, 473
 - tutorials, 477–480
 - View Mates tool, 640
 - views, 451
 - Width mate, 465
 - workflow, 450–451
- Mates folder, 637–638
- MateXpert, 638, 641–642
- MBD (Model-Based Definition), 125
- menus
 - Customize Menu, 37
 - drop-down, 37
 - Insert, 37
 - shortcut menus, 38
 - Tools, 37
 - View, 37
- Window
 - Arrange Icons option, 58
 - Cascade option, 58
 - Close All option, 58
 - New Window option, 58
 - Tile Horizontally option, 58
 - Tile Vertically option, 58
- Merge Result option, 876
 - Feature Scope and, 889–890
- meshes, Face Curves tool, 908
- metadata, 200–201
 - tutorial, 211–212
- MidSurface PropertyManager, 921
- MidSurface tool, 920–921
- Mirror Components tool, 486–488
 - opposite-hand versions, 488–490
 - orientation, 488
- Mirror Entities PropertyManager, 290
- Mirror Entities tool, 72, 289–290
- MirrorComponent icon, 432
- mirroring, 289
 - 3D sketches, 291
 - 3D solids
 - bodies, 308–309
 - features, 309
 - parts, entire, 309–310
 - Dynamic Mirror, 290
 - mirror components, 432, 487
 - opposite-hand versions, 488–490
 - orientation, 488
 - Mirror Entities tool, 289–290
 - tutorial, 311–313
- Miter Flange feature, 963–964
- MMB (middle mouse button), 143, 144–145
- Mode tabs, 26
- Model Items PropertyManager, 788–790
- Model View PropertyManager, 137, 728–729
- Model views, 728–732
 - Cosmetic Thread Display, 730
 - dimensions, 732
 - Display State, 731
 - Display Style, 731
 - Import Options panel, 731
 - multiple views, 730–731
 - open documents, 729
 - Reference Configuration, 730
 - scale, 731–732
 - Select Bodies, 730
 - Start Command When Creating New Drawing, 730
 - thumbnail preview, 730
- modeling
 - assemblies
 - base parts, 416–417
 - bottom-up with mates, 416–417
 - bottom-up with skeleton, 418

- in-context design, 418
 - mates, 416–417
 - best practices, 383–385
 - bottom-up, 605
 - bottom-up assembly, 422
 - feature-based, 15–16
 - history-based, 16–18
 - horizontal, 386
 - hybrid modeling, 907–908
 - in-place, 605
 - master model, 421–422
 - mates, position, 451
 - multibody, 419–421
 - resilient, 386
 - solid modeling, 15
 - top-down, 605
- models, tables in, 836–837
- Modify Configurations dialog box, 344–346
- Modify dialog box, 343
- Modify Dimension box, 83–84, 327–328
- Modify Sketch tool, 80–81, 191–192
- Mold tools, 1107–1109
- Core feature, 1121
 - mold folders, 1111–1112
 - nonplanar parting surfaces, 1123–1124
 - Parting Lines feature, 1113–1115
 - Parting Surface feature, Manual mode, 1117–1119
 - plastic part model
 - applying draft, 1109–1110
 - blank parts and, 1110
 - shelling, 1109–1110
 - Scale feature, 1110–1111
 - shut offs, 1115–1117
 - passing, 1122–1123
 - Tooling Split feature, 1119–1121
- monitors, multiple, 58–59
- motion. *See also* animation
- animation and, 669
 - basic motion, 669
 - creating, 460–462
 - dynamic, 872
 - Dynamic Assembly Motion, 459
 - Exploded View, 670
 - Mate Controller, 670
 - Record Screen, 670
 - walk-throughs and, 669
- motion studies, 669
- MotionManager. *See also* animation
- action speed, 693
 - animation, 670
 - dynamic assembly motion, 670
 - exploded, 678–682
 - key frames, 670
 - playing, 677
 - Animation Wizard, 671
 - Basic Motion, 670
 - camera, paths, 688–690
 - change bar, 671, 676
 - design tree, 671, 673
 - filters, 671
 - formatting output, 673–674
 - interface access, 673
 - key points, 671, 673, 684
 - copying motion, 693
 - creating, 685–686
 - Disable Playback of View Keys, 684
 - interpolation, 687
 - mirroring motion, 693
 - mistake correction, 687–688
 - Orientation and Camera Views, 684
 - timebar, 685, 692–693
 - view manipulation, 686
 - zooming, 686
 - Motion Manager toolbar, 671
 - Motion Study Properties, 673
 - motion study tab, 671
 - playback speed, 673
 - SolidWorks Motion, 670
 - study type, 671
 - timebar, 671, 673
 - timeline area, 671
 - timeline zoom, 673
- mouse
- customizing, 51
 - gestures, 145–146
 - MMB (middle mouse button), 144–145
 - RBM (right mouse button), 145–146
 - spaceball (3D), 144
 - wheel settings, 144
- Move Component tool, 516–519
- Move Entities tool, 190
- Move tool, 76
- Move with Triad tool, 519
- Move/Copy Bodies feature, 877–879, 881–883, 887–888
- multibody modeling, 419–421, 614–615, 871
- adding bodies, 892–893
 - secondary operations, 893
 - starting point, 894
 - versus* assembly modeling, 872–873
 - Body folders, 895–897
 - Boolean operations, Indent feature, 879–881
 - Combine feature, 881–883
 - creating multiple bodies, 875–877
 - cuts, 876
 - Delete/Keep feature, 899–900
 - deleting bodies, 899–900
 - disjointed bodies, connecting, 888
 - Feature Scope, 889–890
 - Delete/Keep Bodies, 890
 - Rib feature, 890
 - hiding bodies, 897–899
 - Insert Part feature, 892–893

- Intersect, 894–895
- local operations
 - Flex feature, 883–884
 - Shell feature, 884–885
 - tutorial, 900–901
- loops, extruding, 875
- Master Model workflow, 878
- Merge Result option, 876
 - Feature Scope and, 889–890
- merging tutorial, 900–901
- Move/Copy Bodies feature, 881–883
- parts, complex, simplifying, 886–887
- patterning, 885–886
 - tutorial, 901–903
- renaming bodies, 900
- shapes, complex, 877–879
- sharing bodies, 876–877
- sheet metal drawings
 - cut list properties, 1013–1014
 - cut list templates, 1015
 - cut lists, placing, 1014–1015
 - cut lists in parts, 1013
 - displaying bodies, 1012–1013
- showing bodies, 897–899
- solids, bridging, 887–888
- Split feature, 890–891
 - planes and, 892
 - sketches and, 891–892
 - surface bodies and, 892
 - tutorial, 901–903
- techniques, 873–874
 - Boolean operations, 874
 - bridges, 875
 - complex shapes, 874
 - geometry, imported, 875
 - local operations, 875
 - patterning, 875
 - solids, bridges, 875
 - tool bodies, 874
 - undetermined manufacturing methods, 875
- tool bodies, Indent feature, 879–881
- troubleshooting, 872
- tutorials
 - local operations, 900–901
 - merging, 900–901
 - patterning bodies, 901–903
 - splitting bodies, 901–903
- undetermined manufacturing methods, 888–889
- uses, 873–874
- multiple-radius fillet, 232
- myths about sketches, 286–287

N

- naming dimensions, equations, 318–320
- navigating 3D sketches, 201–202

- nested contour sketches, 220
- nested loops, 124
- net shape processes, 1073
- networks, template access, 14
- new documents, 8–9
- New SolidWorks Document dialog box, 8, 99
- No Solve Move setting, 91
- Note button, 765
- Note PropertyManager, 138, 775
 - Style panel, 772–773
 - Text Format panel, 767
 - Wordwrap, 766–767
- notes
 - adding, 775
 - alignment, 771
 - balloons, 771–772
 - custom properties, linking to, 774–775
 - Fit Text button, 767
 - fonts, 772–773
 - OLF SimpleSansOC font, 766
 - Format Painter, 774
 - layers, 811
 - leaders, 769–770
 - adding, 770
 - jogged, 771
 - multiple, 770
 - Linear Note Pattern PropertyManager, 767–769
 - linking to custom properties, 847
 - patterns, 767–769
 - placing, 769–770
 - styles, 772–773
 - adding, 773
 - defaults, 773
 - deleting, 773
 - loading, 773
 - saving, 773
 - updating, 773
 - symbols and, 779
 - text boxes, 766–767
 - text wrapping, 766–767
 - workflow, 765–766
- Novice interface, 12
- numbers, Enable On-Screen Numeric Input, 65
- numeric input, 189
- NURBS (Non-Uniform Rational B Spline), 908

O

- Offset Entities interface, 72, 73
 - Add Dimensions option, 72
 - Bi-Directional option, 72
 - Cap Ends option, 72
 - Construction Geometry option, 72
 - Reverse option, 72
 - Select Chain option, 72
- Offset Surface feature, 912–913

- Offset tool, 909
- OLF SimpleSansOC font, 766
- OmniClass, 667
- On-Screen Numeric Input option
- open and closed contours sketches, 220
- Open command, 56
- open contour construction line sketches, 220
- open contour sketches, 220
- Open dialog box, 56
- ordering
 - features, 378–379
 - folders, 379–380
- Ordinate Dimension tool, 86–87
- ordinate dimensions, 86–87, 793–794
- orientation
 - floors, 145
 - views, 750–751
- Overdefining/Not Solved category, 23
- Override Dims on Drag setting, 91
- Overrides, appearances, 160–163

P

- Pack and Go, 645, 646–647
- Page Setup dialog box, 792–793
- palettes, View, 727–728
- Pan tool, 150
- parabola, 77
- Parallelogram tool, 66
- parallelograms, 66
- parasolids, 1049, 1051–1052
- parent/child relationships, 18
 - DRV and, 40
 - master model and, 933–934
 - Rollback and, 372–376
- Part Reviewer, 377–378
- partial ellipse, 77
- parts, 8
 - animation
 - appearance, 671
 - camera, 671
 - position, 671
 - transparency, 671
 - views, 671
 - visibility, 671
 - zoom, 671
 - assemblies and, 429
 - bounding boxes, 872
 - building in place, 520
 - center-of-body calculation, 872
 - chamfers, 135–137
 - complex, simplifying, 886–887
 - configurations, 336, 354–355
 - contour selection, 121–122
 - creating, 61–62
 - starting, 113–116
 - tutorial, 128–136
 - dimensions, 322
 - direct, 124–125
 - display states and, 592
 - dragging, 516–517
 - Along Assembly XYZ, 517
 - Along Entity, 517
 - By Delta XYZ, 517–518
 - Use For Positioning Only option, 513–514
 - To XYZ Position, 518–519
 - Extrude feature, 116
 - end conditions, 118–120
 - Mid Plane, 123–124
 - from selection, 116–118
 - Thin Feature panel, 120–121, 124
 - FeatureManager, new part, 62
 - fillets, 135–137
 - flexibility, 682
 - Free Drag, 516–517
 - geometry, creating, 608
 - in-context, 609–611
 - Instant 3D, 122–123
 - library features, creating, 548–550
 - library parts, 542–543
 - reusing, 872
 - machined, 113
 - Move Component tool, 516–519
 - Move with Triad, 519
 - multibody modeling, 419–421
 - new, 606–607
 - patterns, component patterns, 432
 - properties, custom, 872
 - proximity tools, 520
 - Clearance Verification, 520, 523
 - Collision Detection, 525–526
 - Dynamic Clearance, 523–525
 - Interference Detection, 521–523
 - Physical Dynamics, 526
 - Sensors, 526–528
 - Reload tool, 653–654
 - renaming, 645
 - reusing, 872
 - size, relative, 124–125
 - slots, 134
 - Hole Wizard, 133–134
 - sketched, 133–134
 - subassemblies, 649–650
 - symmetry, 116
 - template, 61–62
 - Paste Appearance tool, 152
 - Path mate, 469
 - path segments, planar, 204
 - Pattern Faces option, 294–295
 - patterns, 283
 - 3D, 291

- bodies
 - solid, 293
 - surface, 293
 - center marks and, 781
 - chain, 492–494
 - Circular, 288–289, 299–300, 484
 - Component, 432, 483
 - component, feature-driven, 491
 - component patterns, 432
 - local, 484–486
 - cosmetic, 307–308
 - Curve-Driven, 300–302
 - faces, 294–295
 - Fill, 303–304
 - fillets, 295
 - Geometry Pattern, 284–286, 292–293
 - Linear, 287–288, 296–299
 - multibody modeling and, 875, 885–886
 - notes, 767–769
 - rebuild times, 285
 - Sketch Pattern tool, 287
 - sketch-driven, 302
 - table-driven, 302–303
 - Variable, 304–307
- PDM (Product Data Management), 14, 200, 645
- Pen Settings, 91
- Pen Sketch tool, 54, 97–98
- Pen tool, 54
- Performance Benchmark, 403–405
- Performance Evaluation tool, 651
- perimeter creation
 - Tangent to Three Entities, 68
 - Tangent to Two Entities, 68
- perspective, 196
- PhotoView 360, animation and, 671
- Physical Dynamics, 526
- pictures, tutorial, 208–211
- Pierce sketch relation, sweeps and, 228–229
- planar path segments, 3D sketches, 204
- planar surfaces, 916
- Plane PropertyManager, 93
 - Flip Normal, 93
- planes
 - 3D, 203
 - axes, 94
 - configurations and, 353–354
 - coordinate systems, 94–96
 - creating, 93–94
 - design tables, 356
- planning animation, 672
- plastic evaluation tools, 1093
 - Draft Analysis tool
 - Basic, 1094
 - Face Classification, 1096–1097
 - Gradual Transition, 1095–1096
 - steep faces, 1097
 - workflow, 1098
 - Thickness Analysis
 - Show Thick Regions option, 1098–1099
 - Show Thin Regions option, 1098
 - workflow, 1099–1101
 - Undercut Analysis, 1100–1101
 - workflow, 1101–1102
- Plastic features, 1073
 - Draft feature, 1083–1084
 - DraftXpert, 1087
 - failure, 1086–1087
 - Neutral Plane draft, 1084
 - Parting Lane draft, 1084–1085
 - Step draft, 1085–1086
 - Indent feature, 1087–1088
 - Lip/Groove feature, 1078–1079
 - Mounting Boss feature, 1074–1076
 - Rib feature, 1079–1080
 - draft, 1080–1081
 - intersection curves, 1081
 - terminating ribs, 1081–1082
- Shell feature, 1088–1089
 - multi-thickness shell, 1089
 - Shell Outward option, 1089–1090
 - workflow, 1090–1091
- Snap Hook feature, 1076–1078
- Snap Hook Groove feature, 1076–1078
- Thin features, 1083
- Vent feature, 1091–1093
- Point tool, 71
- points
 - inflection point, 71
 - reference geometry and, 96
 - splines, 71
- point-to-point Coincident mate, 459–460
- Polygon tool, 77
- polygons, control, 71
- populating assemblies, 126–127
- positioning, floors, 145
- Power Trim tool, 79
- predefined views, 747
- predicting change, 112–113
- primary features, 112
- prismatic shapes, 113–114
- Pro/ENGINEER, 1049
- Profile Center mate, 463
- projected curves, 262, 264
 - sketch on face, 265
 - sketch on sketch, 265
- Projected View PropertyManager, 733
- Projected views, 732–733
- Projection Angle setting, 9
- properties
 - assemblies
 - assigning document driving, 846–847
 - linking notes to, 847
 - configurations, 351–352

- custom, 346–347
 - parts, 872
- cut-list, 872
- formats, 710–711
 - custom data, 711
 - Custom Properties tab, 711–712
 - error display, 713–714
 - link variables, 713–714
 - linked, 714–715
 - links, 712–713
 - Summary Information dialog box, 711
 - mass calculations, 872
 - notes, linking to, 774–775
- Property Managers
 - Insert Part, 893
- Property Tab Builder, 346–347
 - templates, 347
- PropertyManagers, 26, 38, 380–381. *See also* specific
 - PropertyManager
 - 3D Planes, 203
 - Add Dimensions option, 66
 - Add Relation, 71
 - Annotation, 772–773
 - Appearances, 160–163
 - Area Hatch/Fill, 857
 - assemblies, 126
 - Autodimension, 794–795
 - Bill of Materials, 837
 - Block, 775–776
 - Boundary Surface, 912
 - Broken View, 745
 - Camera, 170, 171, 688–689
 - Circle, 67–68
 - Circular Pattern, 289
 - Color, 176
 - Combine, 882–883
 - For Construction option, 70
 - Detached, 26
 - detaching, 42–44
 - Dimension, 84, 318–319, 791
 - displaying, 381
 - Drawing View, 138
 - Edit Scene, 145
 - Emboss, 272
 - Equation Driven Curve, 82
 - Extrude, 120–121, 876
 - Extruded Surface, 909–910
 - FeatureManager split screen, 40
 - Fillet, 135, 232
 - FilletXpert, 236
 - GridSystem, 665
 - Helix/Spiral, 263
 - Indent, 880–881
 - Insert Component, 561
 - Insert Line interface, 65
 - Insert Line option, 65–66
 - Insert Part, 935
 - Library Feature, 540
 - Linear Note Pattern, 767–769
 - Linear Pattern, 288
 - Loft, 226
 - Mate, 450, 642–645
 - Mated Entities, 642, 644
 - MidSurface, 921
 - Mirror Entities, 290
 - Model Items, 788–790
 - Model View, 137, 728–729
 - Note, 138, 775
 - Offset Entities interface, 72
 - Plane, 93
 - Point reference geometry, 96
 - Projected View, 733
 - Relative View, 749
 - Revision Table, 834–836
 - Revolve, 222
 - Scale, 191, 268
 - Scene, 167, 168
 - Section View, 151, 179, 737–738
 - Sensor, 200
 - Sheet Metal, 951–953
 - Sketch Pattern, 767–769
 - Sketch Picture, 193–194, 196, 209
 - Sketch Text, 197
 - Slot, 134
 - Slot sketch entries, 82
 - Snap Hook, 1077
 - Snap Hook Groove, 1077
 - SpeedPak, 864
 - Sweep, 227, 228
 - switching to, 42
 - Text Format, 138
 - Thicken, 916
 - Title Block, 715–716
 - Trim interface, 73
 - Walk-through, 661–663
 - Wrap, 271–272
 - proximity tools, 520
 - Clearance Verification, 520
 - Collision Detection, 525–526
 - Dynamic Clearance, 523–525
 - Interference Detection, 521
 - Component View, 522
 - ignoring interference, 522
 - results display, 522
 - Physical Dynamics, 526
 - Sensors, 526–528
 - Pull functions, 934–935
 - Insert Into New Part feature, 938
 - Insert Part feature, 935–937
 - Push functions, 934–935, 938–939
 - Save Bodies feature, 940–941
 - Split feature, 939–940

Q

Quick Snaps flyout, 72

R

Rack and Pinion mate, 466

Radiate Surface tool, 913–914

Radiate tool, 909

Rapid Dimension manipulator wheel, 791

RapidSketch, 199

RBM (right mouse button), 145–146

RealView tool, 152, 173

Rebuild Block tool, 92

rebUILds

configurations, 342–343

patterns, 285

segmenting, 872

Verification on Rebuild, 388–389

Recent documents, 56–58

Record Screen, 670

records, update holders, 606

Rectangle flyout, 66–67

rectangles

arcs, 187

Corner Rectangle tool, 66

reference dimensions, 790–791

annotation views, 792

autodimensioning, 794–795

baseline, 793–794

DimXpert and, 791–792

ordinate, 793–794

reference sketches, 795

reference entities, 462

reference geometry, 62, 93

assemblies, 428

axes, 93, 94

coordinate systems, 93, 94–96

mate references, 93

planes, 93

creating, 93–94

points, 96

tutorial, 105–109

Reference Geometry toolbar, 93

reference sketches, 795

references

circular references, 427, 503

editing, 183–184

in-context modeling, 611–613

records, update holders, 606

tracking, 386

relations

3D sketches, 202–203

configurations and, 352–353

copying, tutorial, 204–208

design tables, 356

Display/Delete Relations tool, 184–186

editing, 183–184

tutorial, 204–208

Equal, 116

in-context, 427

Replace Entity tool, 186–187

SketchXpert, 188

Symmetry, 291

tutorial, 98–102

relationships. *See also* sketch relations

DRV and, 40

parent/child, 18

relative size, 124–125

Relative View PropertyManager, 749

relative views, 748–749

reliefs, 956–957

Reload tool, 653–654

reloading formats, 719–720

reordering. *See* ordering

Replace Components tool, 647–649

Replace Entity tool, 186–187

Replace Face tool, 921

Replace Mate Entities tool, 642, 644

resilient modeling, 112–113, 386

Revision Table PropertyManager, 834–836

revision tables, 834–836

tutorials, 843–844

Revolve feature, 113

contours and, 223

end conditions, 222

workflow, 222–223

Revolve process, 15

Revolve PropertyManager, 222

Revolve tool, 909

Rhino, 1049

Rib feature, 1079–1080

draft, 1080–1081

intersection curves, 1081

terminating ribs, 1081–1082

RMB menu, 26

Roll View tool, 150

Rollback, 26, 371–372

consumed features, 372

parent-child relationships, 372–376

Rotate About Scene Floor option, 145

Rotate Animation Wizard, 688

Rotate Entities tool, 190

Rotate function (Modify Sketch), 192

Rotate tool, 76

Rotate View tool, 150

rotating

animations, 674–677

Rotate About Scene Floor option, 145

Route Line feature, 853–854

routing, libraries, 543
 Ruled Surface tool, 922–923
 ruled surfaces, 908
 Ruled tool, 909

S

S key toolbar, 38
 "S" menu, 26
 Save As Copy tool, 645
 Save As dialog box, 646
 Save As tool, 645
 Save As with References dialog box, 646
 Save Block/Save Sketch As Block tool, 92
 Save Bodies tool, 934
 Save tool, 645
 saved views, 727–728, 747–748
 saving, views, to DWG/DXF, 748
 Scale Entities tool, 191
 Scale Factor, 269
 Scale feature, 268–269
 Scale PropertyManager, 191, 268
 Scale tool, 76
 scaling, 192, 194
 uniform, 269
 Scan Equal tool, 89
 Scene, Lights, and Cameras DisplayManager, 166
 RMB menu, 170
 Scene PropertyManager, 167, 168
 Scenes (DisplayManager), 157, 165–169
 Ambient Occlusion, 167
 Screw mate, 468
 Scribe feature, 272
 scrollbars, 147–148
 Search options, 46–47
 searches, for files, 47
 second sheet formats, 718–720
 Section View dialog box, 855–857
 Section View PropertyManager, 151, 179, 737–738
 Section View tool, 151–152, 737–738
 section views, 855–857
 Aligned section, 738–739
 alignment, 856–857
 editing, 739
 Half section, 738
 hatching, 856–857
 Isometric Sections, 856
 Partial section, 738
 parts, excluding, 855
 Slice section, 738
 workflow, 736–739
 sections, pop-up toolbar, 737
 Segment tool, 80
 segmenting rebuilds, 872
 Select tool, 77
 Selected Entities category, 23
 Selection Breadcrumb, 26, 381–383
 SelectionManager, 226
 self intersecting contour sketches, 220
 Sensor PropertyManager, 200
 sensors, 199–200
 adding, 527
 dimension, 526
 interference detection, 527
 mass, 526
 measurement, 527
 proximity, 527
 simulation data, 526
 surface area, 526
 volume, 526
 setback fillet, 232, 251–253
 variable radius, 232
 Shaded Sketch Contours, 67, 91
 Shaded tool, 151
 Shaded with Edges tool, 151
 Shadows in Shaded Mode tool, 151
 shapes
 complex, multibody modeling, 877–879
 modeling, global modeling, 275–277
 prismatic, 113–114
 sharing
 bodies, multibody modeling, 876–877
 templates, 14
 sharp edges, estimating, 196
 Sheet Format, 141
 Sheet Format tools
 Automatic Border, 707–708
 Edit Sheet Format, 707
 Title Block Fields, 707–708
 sheet formats, 705
 layers, 810–811
 sheet metal drawing, 1005–1006
 bend areas, 1010–1011
 bend lines, 1008–1010
 bend notes, 1008–1010
 flat pattern, 1006–1008
 bounding box, showing, 1010
 multibody modeling and
 cut list properties, 1013–1014
 cut list templates, 1015
 cut lists, placing, 1014–1015
 cut lists in parts, 1013
 displaying bodies, 1012–1013
 sheet metal features, 949
 Auto Relief, 956–957
 Base Flange method, 949–950
 Base Flange/Tab tool, 950–951
 BaseBend features, 951
 Bend Allowance, 953
 bend calculation tables, 955–956

- Bend Deduction, 954–955
- bend tables, 953–954
 - K-factor, 954
- bend calculation tables, 951–953
- Bend Radius, 953
- Closed Corner feature
 - Break Corner, 969–970
 - Coplanar Faces, 969
 - Corner Trim, 969–970
 - Faces to Extend, 968
 - Faces to Match, 968
 - Gap, 968
 - Open Bend Region, 969
 - Overlap/Underlap Ratio, 968
- conical parts, 990
- Corner Relief feature, 970–971
- Edge Flange feature
 - Angle panel, 961
 - curved edges, 962–963
 - default radius, 960
 - Edit Flange Profile button, 959–960
 - Flange Length, 961
 - Flange Position, 962
 - Gap Distance, 960–961
 - Trim Side Bends, 962
- Flat Pattern feature, 957
 - Convert Entities, 958
 - Corner Treatment option, 958
 - Fixed Face parameter, 958
 - suppressed, 957
- Fold feature, 978–979
- Forming Tool feature, 973
 - creating forming tools, 973–974
 - library, 975
 - placing forming tools, 975
 - techniques, 975–977
- gauge tables, 951–953
- geometry, import geometry starts, 989–990
- Gusset feature, 980
- Hem feature, 964–965
- Jog feature, 965–966
 - Fixed Face, 965–966
 - Fixed Projected Length, 966–967
 - Jog Angle, 967
 - Jog Offset, 966
 - Jog Position, 967
- Lofted Bends feature, 977–978
- method mixing, 990–991
- mirroring, 971–972
- Miter Flange feature, 963–964
- multibody modeling techniques and
 - base flanges, 992
 - Insert Part feature, 991–992
- parts from generic models, 983–984
 - Convert to Sheet Metal feature, 988–989
 - Cut feature, 984–985
 - Flat Pattern feature, 988
 - Flatten Bends feature, 987
 - No Bends, 988
 - Process Bends feature, 987–988
 - Rip feature, 986
 - Sheet Metal feature, 987
 - patterning, 972
 - reliefs, 956–957
 - Sheet Metal PropertyManager, 951–953
 - Sketched Bend feature, 967
 - Swept Flange feature, 979–981
 - Tab and Slot feature, 981–983
 - Thickness, 953
 - tutorials, 992–999
 - Unfold feature, 978–979
- Sheet Metal PropertyManager, 951–953
- Sheet Properties dialog box, 137, 846–847
- sheets, 141
 - versus* views, 30
- Shell feature, 1088–1089
 - multibody modeling, 884–885
 - multi-thickness shell, 1089
 - Shell Outward option, 1089–1090
 - workflow, 1090–1091
- shortcut bars, 38
- shortcut menus, 38
- shortcut tabs, 38
- Shortcut (S) toolbar, 33–34
- shortcuts, 38
- Show Feature History, 896–897
- shut-off faces, 1108
- simulation, 669
- Simulation Display tool, 152
- single hold-line fillets, 247–249
- size
 - relative, 124–125
 - sketch pictures, 193
- skeleton sketches, 387
- sketch blocks, 92
- Sketch button, 64–65
- Sketch Chamfer tool, 69, 87
- Sketch CommandManager, 83
- sketch cursor, 38
- sketch entities. *See* entities
- Sketch Fillet tool, 69
- sketch fillets, 70
- Sketch Ink toolbar, 97–98
 - Pen Sketch tool, 97–98
- Sketch mode, 63
- Sketch Pattern PropertyManager, 767–769
- Sketch Pattern tool, 287
- Sketch Picture PropertyManager, 193–194, 196, 209
- sketch pictures, 81, 193
 - Auto Trace, 196

- edges, sharp, 196
- FeatureManager, 81
- fonts, stick fonts, 196
- perspective and, 196
- scaling, 194
- sizing, 193
- transparency, 194
- views, multiple, 195
- sketch relations
 - blocks
 - adding, 777
 - definition, 777
 - editing, 778
 - existing, 776
 - layers, 778
 - leaders, 778
 - lock angle, 778
 - parameters, 778
 - text / dimension display, 778
 - categories
 - All in This Sketch, 22
 - Broken, 23
 - Dangling, 22
 - Defined in Context, 23
 - External, 23
 - Locked, 23
 - Overdefining / Not Solved, 23
 - Selected Entities, 23
 - coincident, 19
 - suppressed, 23
- Sketch Settings
 - Automatic Relations, 90
 - Automatic Solve, 90–91
 - Detach Segment on Drag, 91
 - Enable Snapping, 91
 - No Solve Move, 91
 - Override Dims on Drag, 91
 - Pen Settings, 91
 - Shaded Sketch Contours, 91
- sketch techniques, 130–132
- Sketch Text, 196–197
- Sketch Text Property Manager, 196–197
- Sketch Text tool, 78
- Sketch tool, 62
 - FeatureManager and, 63
- Sketch toolbar, 63, 64–65
 - 3 Point Arc tool, 69
 - 3D Sketch Plane tool, 71
 - 3D Sketch tool, 65
 - Add Relation tool, 71
 - Centerline tool, 70
 - Centerpoint Arc tool, 68–69
 - Circle tool, center creation, 67
 - Circular Sketch Pattern tool, 80
 - Construction Geometry tool, 75
 - Convert Entities tool, 72
 - Offset Entities command, 72–73
 - Copy tool, 76
 - Corner Rectangle tool, 66
 - Curved Slot tool, 82
 - Display / Delete Relations tool, Quick Snaps flyout, 72
 - Dynamic Mirror command, 80
 - Equation Driven Curve tool, 81–82
 - Extend tool, 79
 - Face Curves tool, 79
 - Grid / Snap tool, 77
 - Intersection Curve tool, 78
 - Line tool, 65
 - Linear Sketch Pattern tool, 80
 - Make Path function, 80
 - Mirror Entities tool, 72
 - Modify Sketch tool, 80
 - Move tool, 76
 - Parallelogram tool, 66
 - Point tool, 71
 - Polygon tool, 77
 - Power Trim tool, 79
 - Rotate tool, 76
 - Scale tool, 76
 - Segment tool, 80
 - Select tool, 77
 - Sketch button, 64–65
 - Sketch Chamfer tool, 69
 - Sketch Fillet tool, 69
 - Sketch Text tool, 78
 - Smart Dimension tool, 65
 - Spline on Surface tool, 77
 - Spline tool, 70
 - Split Entities tool, 80
 - Straight Slot tool, 82
 - Stretch tool, 76
 - Tangent Arc tool, 69
 - Trim tool, 73–75
- sketch-driven patterns, 302
- Sketched Bend feature, 967
- sketches
 - closed contour, 220
 - closed-loop, 218
 - color
 - Edit Sketch Or Curve Color tool, 198
 - lines, 198
 - Color Display Mode, 198
 - construction geometry, 201
 - context bar, 63
 - creating, 62–64
 - dangling, 20
 - defining fully, 87–88
 - derived, 193
 - design intent, 19
 - doubly nested contour, 220

- entities, 64–82
- Fully Defined, 20
- as geometric calculators, 212–214
- GridSystem, 664–665
- inferencing, 89–90
- layout sketches, assemblies, 426–427, 504–505
- lines, 62
 - color, 198
 - style, 198–199
 - thickness, 198–199
- metadata, 200–201
- modifying, 191–192
- myths, 286–287
- nested contour, 220
- open and closed contours, 220
- open contour, 220
- open contour construction line, 220
- opening, 64
- parametrics and, 19
- planar faces, 62
- planes, 62
- RapidSketch, 199
- reference geometry, 62
- reference sketches, 795
- requirements, 16
- self intersecting contour, 220
- sensors, 199–200
- tools, 63
- Underdefined, 20
- unsolvable, 20
- views, converting, 748
- workflows, 62
- wrongly shared endpoints, 220
- zero length, 20
- SketchXpert, 188
- .sldclr documents, 11
- .sldmat documents, 11
- .sldreg documents, 11
- .sldstd documents, 11
- Slot PropertyManager, 134
- Slot sketch entities, 82
- slots
 - center points, 134
 - cutting, 134
 - Hole Wizard, 133–134
 - sketched, 133–134
- Smart Components, 562–566
 - auto-sizing, 566–568
 - creating, 568–570
 - auto-sizing component, 570–574
 - editing components, 575–576
 - file management, 574–575
 - tutorials, 576–579
- Smart Dimension tool, 65, 66, 86, 99, 790–791. *See also* dimensions
 - Autodimension and, 795
 - Instant2D, 83
- Snap Hook Groove PropertyManager, 1077
- Snap Hook PropertyManager, 1077
- snapshots, 146
- Snapshots, LDR and, 660–661
- solid bodies, 871
 - bridges, multibody modeling, 887–888
 - multibody modeling and, 875
 - patterns and, 293
- Solid Edge, 1049
- solid features, 218
 - Intersect feature, 279
- solid modeling, 15, 907–908
 - directions, 117–118
 - extruding, 118–120
- SolidWorks
 - Activation, 5
 - Customer Portal
 - blogs forums, 1172–1173
 - CAD Admin Dashboard, 1172
 - downloads, 1171
 - forums, 1173
 - Forums, 1171
 - installation and administration guides, 1172
 - Knowledge Base, 1171
 - online forums, 1172
 - Release Notes, 1171–1172
 - What’s New, 1172
 - Explorer, assemblies and, 425
 - installation, 3
 - reinstallation, 11
 - Installation Manager, 5
 - license agreement, 6
 - login, 26
 - Motion, 669, 670
 - requirements, 4
 - startup, initial, 6–9
 - tables, *versus* Excel, 821–822
 - Treehouse, assemblies and, 425–426
 - website, 1170
 - Customer Care, 1176
 - system requirements, 1175–1176
 - troubleshooting, 1176
 - website, Downloads area, 4
 - window, viewports, 9
- SolidWorks RX, 400–403
- space handle, 201–202
- specialty features
 - Deboss, 272–273
 - Deform, 275–277
 - Dome, 269–271
 - Emboss, 272
 - Flex feature, 273–275
 - Indent, 277–279

- Intersect, 279
- Scale, 268–269
- Scribe, 272
- Wrap, 271–272
- Specify Configurations dialog box, 343
- speed, file size and, 348–350
- SpeedPak, 432
 - assembly drawings and, 863–865
 - drawings and, 433
 - ghosts, 432–433
 - self-contained data, 433
- SpeedPak PropertyManager, 864
- spirals, 264
- Spline loop, Broken-Out section view, 858–859
- Spline on Surface tool, 77
- Spline tool, 70
- splines, 70
 - control polygon, 71
 - handles
 - direction, 71
 - magnitude, 71
 - inflection point, 71
 - loft comparison, 226–227
 - radius, minimum, 71
 - spline points, 71
 - top vertex, 77
- Split Entities tool, 80
- Split feature, 890–891
 - planes and, 892
 - sketches and, 891–892
 - surface bodies and, 892
- Split Line feature, 262
- split lines, 267
- Split tool, 934
- splitters, 147–148
- Standard 3 View, 733–734
- Standard Views toolbar
 - Front view, 146
 - Normal To view, 146
 - Top view, 146
- status bar, 45–46, 63
- STEP (Standard for the Exchange of Product), 1049
- stick fonts, 196
- stopping face, 973
- Straight Slot tool, 82
- Stretch tool, 76
- style documents
 - .sldgtolft, 10
 - .sldsffvt, 10
 - .sldweldft, 10
- styles
 - dimensions, 802
 - notes, 772–773
 - adding, 773
 - defaults, 773
 - deleting, 773
 - loading, 773
 - saving, 773
 - updating, 773
 - tutorial, 208–211
- subassemblies
 - mates, moving to, 650–651
 - parts, adding and removing, 649–650
 - Treehouse and, 649
- Summary Information dialog box, 711
- suppressed sketch relations, 23
- suppression states, 329
 - configurations and, 350–351
- surface bodies, patterns and, 293
- surface modeling, 905, 907–908
- surfacing, 905–906
 - 3D surfaces, extruding, 910
 - Boundary Surface feature, 911–912
 - Boundary Surface PropertyManager, 912
 - curvature, 919
 - developable surfaces, 908
 - Extend Surface tool, 916–917
 - Extend tool, 909
 - Extrude tool, 909–910
 - Extruded Surface PropertyManager, 909–910
 - extruding, 909–910
 - Fill Surface PropertyManager, 919
 - Fill Surface tool, 918–920
 - Fill tool, 909
 - Fillet tool, 909
 - geometry, degenerate, 908
 - Intersect tool, 923–924
 - Knit function, 906
 - Knit Surface tool, 915
 - Loft tool, 909
 - MidSurface tool, 920–921
 - NURBS (Non-Uniform Rational B Spline), 908
 - Offset Surface feature, 912–913
 - Offset tool, 909
 - planar surfaces, 916
 - Radiate Surface tool, 913–914
 - Radiate tool, 909
 - Replace Face tool, 921
 - Revolve tool, 909
 - Ruled Surface tool, 922–923
 - ruled surfaces, 909, 922–923
 - Ruled tool, 909
 - Sweep tool, 909
 - tangents, 919
 - Thicken Surface tool, 916
 - Thicken tool, 909
 - Trim function, 906–907
 - Trim Surface tool, 917–918
 - Trim tool, 909
 - tutorials

- Cut With Surface feature, 924–925
- Fill Surface blend, 927–930
- Offset Surface command, 925–927

- Untrim function, 907

- Untrim tool, 909

- .swb documents, 11

- Sweep feature, 223, 227

- 3D, 229

- curves, guide curves, 227–228

- Cut Sweep feature, 230–231

- Pierce sketch relations, 228–229

- workflow, 231

- Sweep PropertyManager, 227, 228

- Sweep tool, 909

- .swp documents, 11

- symbol files

- gtol.sym, 11

- swlines.lin, 11

- symbols, 90

- adding, 775

- custom, 780

- dimensions and, 779

- FeatureManager, 651–652

- Geometric Tolerancing symbols, 801–802

- notes and, 779

- symmetric fillets, 232, 240–241

- Symmetric mate, 463–464

- symmetry, 112, 116

- Symmetry relation, 291

- Systems Options Colors dialog box, 47–48

T

- Table views, 345

- table-based BOMs

- appearance, 827

- columns, 828

- combining indented, 827–828

- configurations, 824–825

- dissolving indented, 827–828

- editing, 826–829

- Excel-based, retiring, 829

- indented lists, 827–828

- item numbers, 826

- Keep Missing Items, 825

- numbering indented, 827–828

- restructured indented, 827–828

- rows, 828

- table anchors, 823–824

- templates, 822–823

- types, 824

- Zero Quantity Display, 826

- table-driven patterns, 302–303

- tables

- design tables, 355–356, 830–832

- general tables, 836

- hole tables, 832–834

- tutorials, 841–843

- in models, 836–837

- revision tables, 834–836

- tabulated drawings, 830–832

- tags, 26

- assigning, 46

- Take Snapshot option, 146

- Tangent Arc tool, 69

- tangent arcs, 69

- tangent edges, 754–756

- tangents, 919

- taper helix, 263

- spirals, 264

- Task bar, 26

- Task pane, 26

- Design Library, 538

- DisplayManager, 45

- Appearances, Scenes, and Decals, 43

- Custom Properties, 43

- Design Library, 43

- File Explorer, 43

- Home tab, 43

- Recovered Documents, 43

- SolidWorks Forum, 43

- View Palette, 43

- templates, 347, 705

- assembly drawings, multi-page templates, 847–848

- BibleInchTemplate.prtdot, 99

- blocks in, 724–725

- BOMs (Bills of Materials), 822–823

- changing, 705–706

- custom, 8

- default, 14

- drafting standards, 8

- drawings, 128

- formats, 705

- maintaining, 706

- multiple, 12–14

- network access, 14

- part, 61–62

- predefined views, 720–722

- aligning, 722

- limits, 724

- populating drawings, 722–723

- scaling, 723

- properties, 725

- saving, 725

- sharing, 14

- styles in, 724–725

- templates and formats documents

- .asmdot, 10

- .asmprp, 10

- .drwdot, 10

- .drwprp, 10

- journal.doc, 10

- .prtdot, 10
- .prtprp, 10
- .sldbombt, 10
- .slddrt, 10
- .sldholtbt, 10
- .sldrevtbt, 10
- .sldtbt, 10
- .sldwldtbt, 10
- .xls, 10
- text
 - hyperlinking, 775
 - image placement, 710
 - Sketch Text, 196–197
 - tutorial, 208–211
- text boxes, notes, 766–767
- Text Format PropertyManager, 138
- Thicken PropertyManager, 916
- Thicken Surface tool, 916
- Thicken tool, 909
- thickness, 218
- Thickness Analysis
 - Show Thick Regions option, 1098–1099
 - Show Thin Regions option, 1098
 - workflow, 1099–1101
- Thickness feature, 953
- Thin Feature panel, 120–121
 - Mid-Plane option, 218
 - One-Direction option, 218
 - Two-Direction option, 218
- Thin features, 218, 1083
- Third Angle Projection system, 8
- three-point arcs, 69
- thumbnails, Design library, 546–548
- timeline, 671
- Title Bar, 26, 63
- Title Bar menu, 26
- Title Bar toolbar, 26, 31–32
- Title Block PropertyManager, 715–716
- Tolerance/Precision panel, 801–802
- tolerances, dimensions, 799–800
 - Fit tolerances, 800
 - Geometric Tolerancing symbols, 801–802
 - precision values, 801
- tool bodies, 879–881
- tool tips, 34
- toolbars
 - Blocks, 92
 - CommandManager, 30
 - context toolbars, 32–33
 - Heads-Up View, 31
 - Shortcut (S), 33–34
 - Title Bar, 31–32
 - Curves, 262
 - flyouts, 32, 35–36
 - Formatting, 766
 - Heads-Up View, 143–144
 - Layer, 811
 - moving, 35
 - Reference Geometry, 93
 - S key, 38
 - Sketch, 64–65
 - Sketch Ink, 97–98
 - Standard Views, 146
 - Tools menu, 37
 - top vertex, 77
 - top-down design, 185
 - top-down modeling, 605
 - Touch interface, settings, 97–98
 - Touch Mode interface, 32
 - Pen Settings, 91
 - Touch tool, 54
 - touchscreen support, 53–54
 - tracking references, 386
 - Translate function (Modify Sketch), 192
 - transparency, 194
 - Tree Display, 440
 - Component References, 441
 - components, 440–441
 - configurations, 440–441
 - dependencies, 442–443
 - descriptions, 440
 - feature names, 440
 - features, 442–443
 - mates, 442–443
 - View Mates and Dependencies, 639–640
- Treehouse, assemblies, 649
- Triad, 148–149
- Trim function, 906–907
- Trim interface (PropertyManager), 73
 - Corner option, 74
 - Power Trim option, 74
 - Trim Away Closest option, 75
 - Trim Away Inside option, 74
 - Trim Away Outside option, 75
- Trim Surface tool, 917–918
- Trim tool, 73–75, 909
- troubleshooting
 - common error messages, 398–399
 - dismissing errors, 400
 - mates, 473
 - multibody, 872
 - Performance Benchmark, 403–405
 - rebuild errors, 397–398
 - SolidWorks RX, 400–403
 - SolidWorks website, 1176
- TrueType fonts, 196–197
- tutorials
 - annotations, 782–784
 - assembly arrangement, 443–446
 - assembly configuration, 600–604
 - assembly drawings, 866–868
 - Blocks and Belts, 102–105

- BOMs, 837–840
- bracket casting, 256–260
- circular patterns, 310–311
- color, controlling, 208–211
- component patterns, 495–497
- configurations, 365–368
- cosmetic patterns, 313–314
- design tables, 365–368
- dimensions, tolerances and, 805–808
- Direct Editing tools, 1069–1072
- drawing display tools, 816–818
- drawings, 137–141
- editing techniques, 406–412
- equation use, 330–332
- evaluation techniques, 406–412
- FeatureManager, 446–447
- hole tables, 841–843
- imported geometry, 1067–1068
- in-context modeling, 631–635
- layouts, 507–512
- library features, 579–586
- master model techniques, 941–945
- mates, 477–480
- metadata, 211–212
- mirroring features, 311–313
- multibodies
 - local operations, 900–901
 - merging, 900–901
 - patterning bodies, 901–903
 - splitting bodies, 901–903
- part creation, 128–136
- pictures, controlling, 208–211
- reference geometry, 105–109
- relations, 98–102
 - copying, 204–208
 - editing, 204–208
- repairing solid geometry, 1067–1068
- revision tables, 843–844
- sheet metal features, 992–999
- sketches as geometric calculators, 212–214
- Smart Components, 576–579
- styles, controlling, 208–211
- text, controlling, 208–211
- views
 - option, 756–762
 - settings, 756–762
 - types, 756–762
- visualization, 175–179
- weldments, 1040–1046
- wire-formed part, 280–282
- twists, Flex feature, 273–275
- .txt documents, 11

U

- Undercut Analysis, 1100–1101
- workflow, 1101–1102

- underdefined sketches, 20
- uniform scaling, 269
- Unigraphics/SDRC (NX), 1049
- unsolvable sketches, 20
- Untrim function, 907
- Untrim tool, 909
- update holders, 606
- Use For Positioning Only option, 513–514

V

- Variable pattern, 304–307
- Variable Pitch helix, 262
- variable-radius fillets
 - transitions, 245
 - uses, 245
 - values, 243–244
- variables, global, 326–327, 424
- variable-size fillet, 232
- Vent feature, 1091–1093
- Verification on Rebuild, 388–389
- Vertical Dimension tool, 86
- View Bounding Box tool, 152
- View indicator, 26
- View Mate Errors window, 641
- View Mates and Dependencies, 639–640
- View Mates tool, 640
- View menu, 37
- View Orientation dialog box, 154–156
- View Orientation toolbar, 150
- View Orientation view, 747–748
- View palette, 727–728
- View toolbar
 - customizing, 146
 - Take Snapshot option, 146
 - tools, 147
- viewports, 9
- views, 143
 - 3D Drawing View, 150, 749–750
 - alignment and, 750–751
 - alternate position, 745–747, 849–850
 - Ambient Occlusion tool, 152
 - animating, 683–684
 - key points, 684–688
 - annotation views, 156–157, 728–729
 - appearances, 160
 - applying, 157–158
 - Display States and, 163
 - versus materials, 159–160
 - Overrides, 160–163
 - removing, 164–165
 - Apply Scene tool, 152
 - arrow keys, 144
 - auxiliary, 745
 - Break, 743–745
 - Broken-Out section, 858
 - closed loop, 858–859

- depth, 859
- editing, 860
- properties, 860
- Broken-Out Views, 740–743
- Cartoon tool, 152
- Change Display States tool, 153
- color
 - applying, 174
 - assembly drawings, 860–861
- converting to sketches, 748
- Copy Appearance tool, 152
- Crop, 740
- Detail, 734–736
- DisplayManager
 - Appearances, 157
 - Cameras, 157, 165–166, 170–173
 - Decals, 157, 165
 - Lights, 157, 165–166, 169–170
 - RealView, 173
 - Scenes, 157, 165–169
- displays
 - display states, 751
 - display styles, 751–752
 - layers, 752–753
 - tangent edges, 754–756
- Draft, Undercut, and Parting Line Analysis tool, 152
- edges, 174
- Edit Appearance tool, 152
- empty, 747
- exploded, 850–854
- Heads-Up View toolbar, 143–144
- Hidden Lines Removed (HLR) tool, 151
- Hidden Lines Visible (HLV) tool, 151
- Hide All Types tool, 153
- Magnifying Glass, 148
- Model, 728–729
- mouse, MMB (middle mouse button), 144–145
- mouse gestures, 145–146
- multiple, 195
- orientation and, 750–751
- Pan tool, 150
- Paste Appearance tool, 152
- predefined, 747
- Projected, 732–733
- RealView tool, 152
- relative, 748–749
- Roll View tool, 150
- Rotate About Scene Floor option, 145
- Rotate View tool, 150
- saved, 727–728, 747–748
- saving, to DWG/DXF, 748
- scrollbars, 147–148
- section, 855–857
 - alignment, 856–857
 - hatching, 856–857
 - Isometric Sections, 856
 - parts, excluding, 855

- Section, 736–739
- Section View tool, 151–152
- section views, 855–857
- Shaded tool, 151
- Shaded with Edges tool, 151
- Shadows in Shaded Mode tool, 151
- versus* sheets, 756
- Simulation Display tool, 152
- splitters, 147–148
- Standard 3 View, 733–734
- Table views, 345
- Triad, 148–149
- View Bounding Box tool, 152
- View Orientation, 747–748
- View Orientation toolbar, 150
- View Quality settings, 755–756
- Walkthrough tool, 153
- Wireframe tool, 150
- Zebra Stripes tool, 153–154
- Zoom about Screen Center tool, 150
- Zoom In/Out tool, 150
- Zoom to Area tool, 150
- Zoom to Fit tool, 149
- Zoom to Selection tool, 150
- virtual components, 428, 607–608
 - saving, 609
- Virtual Parts, 606
- visualization, 143. *See also* views
 - tutorial, 175–179
- VOR (Verification on Rebuild), 284

W

- Walk-through PropertyManager, 661–663
- Walkthrough tool, 153
- walk-throughs, 661–663
 - DisplayManager, 662
 - motion and, 669
 - workflows, 663
- warnings *versus* errors, 638
- Welcome to SolidWorks dialog, 7
- weld beads, 558–560
- Weldment tools
 - Arc Segments, 1028–1029
 - configurations, 1029
 - patterning bodies, 1029
 - symmetry, 1029
 - cut lists, 1033–1034
 - excluding items, 1034–1035
 - properties, 1034
 - reordering items, 1034–1035
 - End Cap feature, 1030
 - Fillet Beads, 1036–1038
 - Gusset feature, 1030
 - nonstructural components, 1032
 - profiles, custom, 1026–1029
 - Structural Member feature

- contiguous groups, 1024
- disjoint sketch segments, 1025–1026
- groups, 1024–1025
 - parallel groups, 1024
 - path segment groups, 1024–1025
 - profile orientation, 1025
- sub-weldments, 1032
- Trim/Extend feature, 1029–1030
- Weld Beads, 1036–1038
- Weldment button, 1022
- Weldment Properties, 1022–1023
- Weldment toolbar, 1022
- weldments
 - 3D sketches, 1017–1018
 - dimensions, 1021–1022
 - navigating, 1018–1019
 - path segment limits, 1021
 - plane creation, 1020–1021
 - sketch relations, 1019
 - drawings, creating, 1038–1039
 - tutorial, 1040–1046
- Width mate, 465
- Window expander, 26
- Window menu
 - Arrange Icons option, 58
 - Cascade option, 58
 - Close All option, 58
 - New Window option, 58
 - Tile Horizontally option, 58
 - Tile Vertically option, 58
- windows
 - documents, multiple, 55
 - monitors, multiple, 58–59

- wire-formed part, tutorial, 280–282
- Wireframe tool, 150
- workflows, 62, 218–219
 - assembly layouts, 501
 - exploded view creation, 850–854
 - Extrude feature, 219
 - Helix curves, 264
 - Master Model, 878
 - notes, 765–766
 - Section Views, 736–739
 - walk-throughs, 663
- Workspace menu, 32
- Wrap feature, 271–273
- Wrap PropertyManager, 271–272
- wrongly shared endpoints sketches, 220

X

- .xls documents, 11

Z

- Zebra Stripes tool, 153–154
- zero length sketches, 20
- Zoom about Screen Center tool, 150
- Zoom In/Out tool, 150
- Zoom to Area tool, 150
- Zoom to Fit tool, 149
- Zoom to Selection tool, 150
- zooms, animating, 682